

# Rio Grande

#### **Models:**

PTRIOBRK08 - Rio Grande 8', Weathered Bark PTRIORVN08 - Rio Grande 8', Weathered Raven



Congratulations on selecting a Rio Grande slate pool table - part of the Fairfield Collection by Playcraft. Please contact us ia email at support@playcraft.com should you require any assistance.

#### Please carefully read all safety instructions and directions before proceeding

- 1) Your table is designed for use indoors in a climate controlled environment only. Damage can occur if the table is exposed to water, dampness, high humidity, freezing temperatures, etc.
- 2) Professional assembly is strongly recommended. This assembly manual is intended to guide an experienced slate pool table installer with the assembly process of this specific cabinet. It does not guide on setting the slate or attaching the billiard cloth for which the process is the same regardless of the cabinet type.
- 2) The pool table cabinet and slate are extremely heavy. Two or more people are required for assembly.
- 3) The table must be assembled in the final location where the table will be played. Attempting to move the table once assembled could result in damage to the table or serious injury.
- 5) Only use the table for its intended purpose.
- Damaged or worn parts may be dangerous for users and the integrity of the table.

  Replace worn or damaged components immediately and do not use the table until any issues have been resolved. For best results, use only spare parts supplied by Playcraft.
- 7) Unauthorized repairs or alterating the table's design or functions may be dangerous and will void the warranty.
- 8) Check all screws, bolts, etc. on a regular basis to ensure that they are in good working condition and have not loosened over time.
- 9) Over time, pool tables may require releveling. This is considered normal maintenance as required with owning a slate pool table





#### **HARDWARE LIST**

NO.         REF.         PARTS         SPECIFICATION         QTY         UN           A         FLAT HEAD SCREW         4.2*30         6         PC           CONNECTION OF ROUND TUB AND LEGS         ASSEMBLY           B         FLAT WASHER         M10         4         PC           CONNECTION FOR CROSS BEAMS         ASSEMBLY           HEX BOLT         Ø12*180         4         PC           CONNECTION FOR CROSS BEAMS         ASSEMBLY           FLAT HEAD SCREW NUT         M12         4         PC           CONNECTION FOR CROSS BEAMS         ASSEMBLY           FLAT HEAD SCREW         4.2*60         8         PC           CONNECTION FOR MIDDLE BEAMS         ASSEMBLY           HEX BOLT         Ø10*60         4         PC           CONNECTION FOR BAEM AND LEGS         ADJUSTABLE SCREW         Ø10*100         12         PC           G         TO ADJUST AND LEVELING THE SLATE         ASSEMBLY           ADJUSTABLE SCREW         Ø10*55         4         PC           TO ADJUST AND LEVELING THE SLATE         ASSEMBLY           FLAT HEAD SCREW         6*60         12         PC	S POSITION	
A CONNECTION OF ROUND TUB AND LEGS ASSEMBLY  B FLAT WASHER M10 4 PC  CONNECTION FOR CROSS BEAMS ASSEMBLY  HEX BOLT Ø12*180 4 PC  CONNECTION FOR CROSS BEAMS ASSEMBLY  D SEMICIRCLE SCREW NUT M12 4 PC  CONNECTION FOR CROSS BEAMS ASSEMBLY  FLAT HEAD SCREW 4.2*60 8 PC  CONNECTION FOR MIDDLE BEAMS ASSEMBLY  F CONNECTION FOR MIDDLE BEAMS ASSEMBLY  HEX BOLT Ø10*60 4 PC  CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW Ø10*100 12 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	POSITION	
CONNECTION OF ROUND TUB AND LEGS  ASSEMBLY  FLAT WASHER  M10  CONNECTION FOR CROSS BEAMS  ASSEMBLY  HEX BOLT  D  SEMICIRCLE SCREW NUT  CONNECTION FOR CROSS BEAMS  ASSEMBLY  FLAT HEAD SCREW  FLAT HEAD SCREW  CONNECTION FOR MIDDLE BEAMS  ASSEMBLY  FLAT BOLT  HEX BOLT  CONNECTION FOR MIDDLE BEAMS  ASSEMBLY  FLAT BOLT  CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW  M10*100  12  PC  TO ADJUST AND LEVELING THE SLATE  ASSEMBLY  ASSEMBLY  TO ADJUST AND LEVELING THE SLATE  ASSEMBLY		
CONNECTION FOR CROSS BEAMS   ASSEMBLY	S	
CONNECTION FOR CROSS BEAMS   ASSEMBLY		
CONNECTION FOR CROSS BEAMS   ASSEMBLY	POSITION	
CONNECTION FOR CROSS BEAMS   ASSEMBLY	S	
CONNECTION FOR CROSS BEAMS   ASSEMBLY	ASSEMBLY POSITION	
CONNECTION FOR CROSS BEAMS   ASSEMBLY	S	
F CONNECTION FOR MIDDLE BEAMS ASSEMBLY  HEX BOLT Ø10*60 4 PC  CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW Ø10*100 12 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	POSITION	
F HEX BOLT Ø10*60 4 PC  CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW Ø10*100 12 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	S	
G CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW Ø10*100 12 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	POSITION	
CONNECTION FOR BAEM AND LEGS  ADJUSTABLE SCREW Ø10*100 12 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	S	
TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY		
TO ADJUST AND LEVELING THE SLATE ASSEMBLY  ADJUSTABLE SCREW Ø10*55 4 PC  TO ADJUST AND LEVELING THE SLATE ASSEMBLY	S	
H TO ADJUST AND LEVELING THE SLATE ASSEMBLY	POSITION	
TO ADJUST AND LEVELING THE SLATE ASSEMBLY	S	
FLAT HEAD SCREW 6*60 12 PC	POSITION	
	S	
TO FIX THE SLATE ASSEMBLY	POSITION	
HEX BOLT Ø8*80 8 PC	S	
CONNECTION FOR RAILS ASSEMBLY	POSITION	
SEMICIRCLE WASHER M8 8 PC	S	
CONNECTION FOR RAILS ASSEMBLY	POSITION	
NUT M8*30 8 PC		
CONNECTION FOR RAILS ASSEMBLY	S	
FLAT WASHER M8 20 PC		
CONNECTION FOR PANELS AND RAILS ASSEMBLY	POSITION	
N HEX BOLT Ø8*30/Ø8*40 8+12 PC	POSITION S	
CONNECTION FOR PANELS AND RAILS ASSEMBLY	POSITION S POSITION S	
HEX BOLT Ø10*60 18 PC	POSITION S POSITION S POSITION	
CONNECTION FOR RAILS AND SLATE ASSEMBLY	POSITION S POSITION S POSITION	



#### **HARDWARE LIST**

Р	3	DOME WASHER	M10	18	PCS
		CONNECTION FOR RAILS AND SLATE			ASSEMBLY POSITION
	<b>*</b>	WOODEN PLUG		1	PCS
Q		POCKET			ASSEMBLY POSITION
	-	FLAT HEAD SCREW	4.2*20	12	PCS
S		POCKET			ASSEMBLY POSITION
Т		WOODEN PLUG	ø10*50	2	PCS
		CONNECTED #2 AND #3 TOP RAIL			ASSEMBLY POSITION



# **PARTS LIST**


NO.	DESCRIPTION	ITEM	SPECIFICATION	QTY	UNIT
1		LEG		2	PCS
		ASSEMBLY POSITION		FRAME	
		ROUND TUBE		1	PC
2		ASSEMBLY POSITION		FRAME	
		LARGE NUT		2	PC
3		ASSEMBLY POSITION			
		CROSS BEAM		2	PCS
4		ASSEMBLY POSITION		FRAME	
		LONGITUDINAL BEAM		2	pcs
5		ASSEMBLY POSITION		FRAME	
		MIDDLE BEAM		2	PCs
6		ASSEMBLY POSITION		FRAME	
7		SIDE SLATE1		1	PC
		ASSEMBLY POSITION		RAILS	
		MIDDLE SLATE		1	PC
8		ASSEMBLY POSITION		RAILS	




# **PARTS LIST**


NO.	DESCRIPTION	ITEM	SPECIFICATION	QTY	UNIT
9		SIDE SLATE2		1	PC
		ASSEMBLY POSITION	RAILS		
10		CLOTH		1	PC
	2	POSITION		RAILS	
		#1-#4 TOP RAIL		2	PCS
11		ASSEMBLY POSITION		RAILS	
		APRON MITRER		2	PCS
12		ASSEMBLY POSITION		RAILS	
		#2-#5 TOP RAIL		2	PCS
13		ASSEMBLY POSITION		RAILS	
		#3-#6 TOP RAIL		4	PCS
14		ASSEMBLY POSITION		RAILS	
	pase)	SLATE		2	PCS
15		ASSEMBLY POSITION		RAILS	
		SLATE		2	PCS
16	<u>4</u>	ASSEMBLY POSITION		RAILS	





















































#### **Customer Service**

For questions on assembly or for missing or damaged parts, please contact us via email at support@playcraft.com. Please visit our website at www.playcraft.com to see more industry leading Playcraft and Playcraft Sport game tables.

### Thank you for choosing Playcraft!

Global Merchants, Inc. 12 Lunar Drive Woodbridge, CT 06525