

INSTRUCTIONS FOR NEWGY PONG-PAL

Congratulations on the purchase of your Newgy Pong-Pal. Pong-Pal will make it much easier and quicker to pick up table tennis balls. With its special angled end, you can even retrieve balls that are under your table or other obstacle (see Photo A). Your back will thank you!

Its two piece design permits you to take it apart and carry it in your sport bag or Robo-Tote. Wheelchair players may desire to use only the lower half and then place it in the seat of their wheelchair or on their arm rest (as shown) when they're not using it (see Photos B & C). That way it's always handy to assist even with the pick-up of a single ball.

To assemble, simply push the bottom of the top piece into the flared end of the bottom piece (see Photo D). To make sure the connection is as tight as possible, it will help if you twist the pieces as you're pushing them together.

To use, place the angled end over a ball and then press down and forward (See Photo E). The ball will pop through the flexible band and be captured in the tube. Continue picking up balls until the tube is full (approximately 23 balls). Carry the tube over to your robot, turn the tube upside down, and the balls will roll out and into the robot's ball tray (See Photo F).

Your Pong-Pal is also handy to help clear balls off your table after a session with your robot. If there are several balls lying on top of the table, place the Pong-Pal on the table close to the table net and roll it toward the robot, pushing the balls back into the robot's ball trays (See Photos G & H).

The enclosed piece of Velcro is for attaching the Pong-Pal to the side of your table tennis table, or other location, where it will be handy when you're ready to use it. You may attach it either horizontally or vertically (see Photos I & J). We've also enclosed 2 extra flexible bands to replace the original when it wears out.

