



Be part of the TIBO family:


Subscribe to our YouTube channel

Like us on Facebook

Product support:

www.tibo-audio.com

info@tibo-audio.com



Choros Porta

Quick Start Guide



Thank you

for purchasing the TIBO Choros Porta.

We are confident that it will provide
reliable, high performance sound for
many years to come.

To set up, please...

Download the app:



Android




iOS

Follow the instructions on screen
Sign up for news and software updates:
<http://tibo-audio.com>

Play & Enjoy!

TIBO Top Panel



1. Group / Pre-set:
 - Long Press: To group multi-speakers
Press again to ungroup
 - In Wi-Fi mode recall direct preset stations
 - Short Press: Scroll through stations 1-5
2. Power / Mode:
 - Long press: Turn on / Standby
 - Short press: Scroll to Bluetooth / Wi-Fi / Line in
3. Play / Pause / Pair:
 - Short Press: Pause / Play
 - Long Press: Bluetooth mode pairing
4. Minus : Decrease volume
5. Plus: Increase volume

TIBO LED Light

6. Group:
 - White Light: Speaker in multi-speakers group mode
7. Battery:
 - Steady Red Light: Charging
 - Flashing Red Light: Low battery
8. Mode:
 - Red Light: Wi-Fi mode
 - Blue Light: Bluetooth mode
 - Green Light: Line in mode



TIBO Rear Panel

1. USB DC in:
 - Power micro USB port for charging (use lead supplied)
2. Line in:
 - 3.5 mm audio stereo input
 - Connection of external devices for playback
3. WPS:
 - Link the speaker to the Wi-Fi network by following the app instructions
 - In Wi-Fi mode, press this key and hold down for 5 seconds and release to reset back to factory settings

