GSM USB Dual iPhone style charger instructions

Dual USB iPhone style phone charger with premium quality audio monitor with built in sound recorder & call back with tracker locator feature. Operates on AC mains indefinitely when plugged in socket & small internal battery for up to 3 hours unplugged. Call & listen, record sound, track / locate, set voice activated call back, motion alarm & more.

Step 1: Insert nano sim card - (A 'PAYG' sim card is already fitted inside & only necessary if inserting your own sim card - go to step 2 if not inserting new sim card) remove cover & locate sim card holder, unclip holder & gently lift up metal hinge, insert sim with copper contacts faced down & clip back hinge. Not all sim cards are compatible, some networks work better than others depending on location, use Vodafone, O2 or EE sim for best results. Minimum £5/£10 credit is required on sim card & can be added when in device. If possible avoid inserting sim in phone to add credit / top up, insert sim into GPS09, power up GPS09 & contact sim card provider to add credit by paying over phone, online or via their app. Some methods of top up require code sent to phone for credit to be added, insert sim in phone & check security pin is not added to sim otherwise it will not work in

Step 2: Switch on by plugging charger into wall socket or open up charger & hold down on/off button for 2-3 seconds. Red LED lights up when battery charging & blinks when ready to use. If not moved LED turns off, if moved LED blinks this is movement sensor. LED on constant - battery charging, LED blinking device is working. GPS09 is ready to use, add credit to sim if needed, credit / top up is only required if using all features, to use listening device only no credit / top up is required.

Step 3: Switch on voice monitor mode & bind mobile number to device by sending sms text from your mobile phone - Monitor#ENTER YOUR NUMBER HERE# this binds your step 3: Switch on voice monitor index & unit indoe a bill indoe is bill indoe in the index of th

Step 4: Call device / sim number to check voice monitor is switched on & has accepted your number to call in. If answer phone or not possible to connect your call is heard repeat step 3. If no signal is available, number is not stored successfully, voice monitor is off device will not connect. If device is connected to network but number not stored or voice monitor off you will get half ring before cutting off / answer phone. If not connected to network it will not ring at all & immediately ends call. Check battery, place near window for better reception & repeat step 3. Please note: sim card fitted may not be the best to use in your area and consider replacing this if no connection can be established.

Step 5: Sim card must have credit to use sound activated call back & requires setting administrator number by texting - 000#ENTER YOUR NUMBER HERE# - device replie text - Administrator is saved. Next Send text - 333, device replies - record call alarm. Any sound above 60db for 3-5 seconds is required for it to call you. This can be voices, door closing, foot steps, music, background noises etc. Silicon (MEM) microphone is voice intelligent avoiding false alarms, when installing position in open space & as close to target area for best results. Do not place device near TV, radio, music speaker & as close to intended target for best result. When activated device calls you to answer / listen & will use credit on sim when answered. Cut off anytime & call back if required.

Step 6: Sound recorder requires memory card (8GB or 32GB) inserted into metal holder over top of sim card (picture below). Slide memory contacts faced down (logo faced up) over top of sim card into holder. Please note: insert memory with device switched off otherwise it will not recognise memory inserted. Memory is recognised by device when first booting up, switch off device (step 5) insert memory & switch back on (step 2). Recorder has 2 modes, one off 10 minute record & sound activated record. Both modes record 10 minute files saving each file named with date/time stamp 2107251530500. 21 Year 07 month 25 day 15 hour 30 minutes 05 seconds 00 file number.

Step 7: start/stop sound recorder - one off 10 minute record; send text - 111 to device, it replies with text - start record 10. Device records for 10 minutes & stops recording. To stop recorder send text - 555, reply text - turn off all function. Sound activated record; send text - 222, reply text - sound record 10. Any sound above 60db starts recorder for 10 minutes. The microphone is sensitive enough to hear voice over 5 metres at lower levels of 35db but sound activation is fixed at 60dB. This avoids false recordings, sound above 60db at constant level for 3-5 seconds is required to start recorder. This avoids recording one off sounds like a car passing by or dog bark is heard. Continuous voice or sound will trigger recorder this includes door closing, foot steps, music & other background noise. Sound activated recorder is not guaranteed to record everything & ignores sound that is not in the speech frequency. in the speech frequency.

Step 8: Track / locate device: this is not a GPS tracker & not its primary purpose. You can use step 10 below to locate device by texting 999 to device. You can also use GPS365 app downloaded from app store. Open app & login entering unique 15 digit IMEI number (label on side of device or text imei# to device & it reply with 15 digit imei number) enter imei & password 123456 to open app & use tracking app. Please remember this is not a proper tracker & may be inaccurate at times. Logged into app displays main menu, tap on track to see current location showing icon in centre of map. Tap on icon in centre of screen to display current status, signal strength, battery status, last known position, last communication time, address (tap on address to display). Top right of screen displays refresh & map display settings (Google / Baidu). Bottom left sight button shows your phone location on map & bottom right arrow shows direction & distance on map. Please note: GPS365 app is for use with all types of trackers with or without GPS & has many features that are not relevant to this device. What is useful feature in app is the remote shutdown of device & sound record clips to app however it describes one of the sound recorded & good idea of what is going on pear device. This type of trackers with or without of credit & data on similar to continue. recording file. However it does give some of the sound recorded & good idea of what is going on near device. This type of usage requires plenty of credit & data on sim to continue operating without interruption.

Step 9: Vibration/movement alarm: Send text 666 - replies with text - turn on motion sms alarm. Device will send text - motion alarm: IMEI number (15 digit number) when vibration or movement is detected. You can set to audio call instead by sending text - 777, replies with text - turn on motion call alarm, device will audio call instead of texting when vibration or movement is detected. To turn off vibration/movement alarm text - 555, reply - turn off all function.

Step 10: Check battery / Locate device by text - send text - 999, device reply BAT=100%,http://www.08gps.com/lb-sphp?x=Xq3XX3ncq0Xncn3zf. Tap on blue link to open Google maps via the 08gps.com website. This requires internet connection to phone to open Google maps & show location. This is not a GPS tracker & accuracy depends solely on GSM signal strength & accurate within 5-2500 metres depending on current signal strength.

Step 11: Turn off Red LED: Send text - LED#off#, this turns off blinking LED if you are concerned it may be seen. To turn back on, send text - LED#on#.

Step 12: Switch off device by letting battery run down or open charger, hold down on/off button for 10 seconds until LED stops blinking / lights up & release button to turn off.

Do not activate more than one function at a time, for example if recording sound & you call device this stops recorder & answers call to use voice monitor. Each comm& will deactivate last function to start new function. If you call voice monitor whilst recording remember to restart recorder when finished if you want to continue recording. Now you have set up basic function of device you can download GPS365 app to set up more advanced operations. Includes power saving / remote shutdown / timer / geo fencing / wifi / tracking.

All SMS text comm&s & settings (use upper/lower case where shown)

000#ENTER YOUR NUMBER HERE# to bind your number to device. If your number is 07796 123456 send text containing 000#07796123456#. Reply text - Administrator is saved. Store up to 3 different numbers by sending text - 000#number 1#number 2#number 3# Leave out number 3 if storing 2 numbers - text 000#number 1#number 2#11 - Start sound recording for 10 minutes, Device reply - start record 10

222 - Start sound activated recorder, Sound records for 10 minutes, Device reply - Sound record 10

333 - Turn on voice activated audio call back, Device reply - record call alarm.

444 - Delete contents of memory card - Device reply - turn off all function.

666 - Turn on vibration activated audio call back, Device reply - turn on motion sms alarm.

777 - Turn on vibration activated audio call to designated number only, Device reply - turn on motion call alarm.

999 - SMS co-ordinates / Tracker location, Device reply - 311450000123456 unique 15 digit imei number.

1122 - Restore to factory settings from designated number only, Device reply - OK

LED#off# - Turn on LED lights, Device does not reply - OFF

LED#on# - Turn on LED lights, Device reply - ON









Close hinge cover and pull back to lock into place





Insert memory sliding over



Telephone Support - 01962 859426