


JUMP SLIDER

Trampoline Ramp Slide

Model No. 200071



*Read and follow all steps in manual before
assembling and using this unit.*

Keep this manual so you can refer to it in future.

TRAMPOLINEPRO^{COM}

Tel: 1-800-473-5867
www.trampolinepro.com

User's Manual

Read these materials prior to assembling and using this trampoline ramp slide. Keep this manual so you can refer to it later. Trampolines over 20 in. (51 cm) tall are not recommended for children under 6 years of age. It is strongly recommended that the customer, purchase, install and maintain an enclosure that complies with Safety Specification F381-09.

Table of Contents

Assembly and Installation Instructions.....	3
Care and Maintenance Instructions.....	3
Use Instructions.....	4
Assembly.....	5-8
Exploded Drawing and Part List.....	9
Limited Warranty.....	10

Thank you for your trampoline ramp slide purchase, you are now the proud owner of the JumpSlider by Trampoline Pro. We hope you have as much fun using your new trampoline ramp slide as we had bringing it to you. Below, we have included some tips and best practices for trampoline and trampoline accessory use, assembly, and maintenance. Please take a moment to review these notes and warnings so you can have fun on your new JumpSlider and safely enjoy your trampoline for years to come. These general trampoline warnings are provided as an added benefit, but always refer to your trampoline owner's manual for further instructions specific to your system.

QUESTION?

If you have questions after reading this manual, please call our toll-free Customer Care Hot Line. The trained technicians on our Customer Care Hot Line will provide immediate assistance.

Customer Care Hot Line: 1-800-473-5867

Monday - Friday, 8a.m. - 5p.m. MountainTime



WARNING: **General Trampoline Assembly and Installation**

- Adequate overhead clearance is essential. A minimum of 24 ft (7.3 m) from ground level is recommended. Provide clearance for wires, tree limbs, and other possible hazards.
- Lateral clearance is essential. Place the trampoline and trampoline enclosure away from walls, structures, fences, and other play areas. Maintain a clear space on all sides of the trampoline and trampoline enclosure. A minimum of six feet from frame edge is recommended.
- The trampoline is heavy and is under heavy tension. Three able-bodied adults are required to set it up. Use appropriate clothing and shoes. Failure to follow these instructions may lead to injury or damage to the trampoline.
- Never set-up the trampoline in heavy rain, wind or storm conditions, especially lightning storms. It is recommended that the trampoline be taken apart and stored in bad weather.
- When moving the assembled trampoline, have at least four people evenly spaced around the frame (NSEW) to lift the trampoline off the ground.
- Place the trampoline and trampoline enclosure on a level surface before use.
- Use the trampoline and trampoline enclosure in a well-lit area. Artificial illumination may be required for indoor or shady areas.
- Secure the trampoline and trampoline enclosure against unauthorized and unsupervised use.
- Remove any obstructions from beneath the trampoline and trampoline enclosure.
- The owner and supervisors of the trampoline and trampoline enclosure are responsible to make all users aware of practices specified in the "Use Instructions".
- The trampoline enclosure is only to be used as an enclosure for a trampoline and the trampoline must be of the appropriate size as covered by the specific enclosure.



WARNING: **Trampoline Care and Maintenance Instructions**

Inspect the trampoline and trampoline enclosure before each use and replace any worn, defective, or missing parts.

The following conditions could represent potential hazards:

1. Missing, improperly positioned, or insecurely attached frame padding, barrier or enclosure support system (frame) padding and pole caps.
2. Punctures, frays, tears, or holes worn in the bed or frame padding, barrier or enclosure support system (frame) padding and pole caps.
3. Deterioration in the stitching or fabric of the bed or frame padding, barrier or enclosure support system (frame) padding and pole caps.
4. Ruptured springs or bands.
5. A bent or broken frame or support system.
6. A sagging barrier or bed.
7. Sharp protrusions on the frame or suspension system, or
8. Loosened or missing hardware.




WARNING: Use Instructions

- Use two or more strong people to open and close folding-type trampolines. The strong people should always be adults.
- DO NOT attempt or allow somersaults on the Trampoline. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.
- Do not allow more than one person on the trampoline or inside the trampoline enclosure. Use by more than one person at the same time can result in serious injuries.
- Keep objects away which could interfere with the performer. Maintain a clear area around the trampoline. Do not allow foreign objects or animals on the trampoline.
- Use trampoline and trampoline enclosure only with mature, knowledgeable supervision.
- Trampolines over 20 in. (51 cm) tall are not recommended for use by children under six years of age.
- The trampoline should be assembled in its entirety before each use. All springs should be attached to the frame. The frame cover should be positioned correctly at all times.
- Never set-up the trampoline in heavy rain, wind or storm conditions, especially lightning storms. It is recommended that the trampoline be taken apart and stored in bad weather.
- When moving the assembled trampoline and trampoline enclosure have at least four people evenly spaced around the frame (NSEW) to lift the trampoline off the ground.
- Inspect the trampoline and trampoline enclosure before each use. Make sure the frame cover, barrier and, enclosure support padding are correctly and securely positioned. Replace any worn, defective, or missing parts.
- The metal frame of the trampoline will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the trampoline.
- Wear comfortable clothing. Remove jewelry, necklaces, and earrings. Wear clothing free of draw strings, hooks, loops or anything that could get caught in the barrier.
- Climb on and off the trampoline. Enter and exit the enclosure only at the enclosure door or barrier opening designated for that purpose. It is a dangerous practice to jump from the trampoline to the ground or floor when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
- Learn fundamental bounces and body positions thoroughly before trying more advanced skills. A variety of trampoline activities can be carried out by performing the basic fundamentals in various series and combinations, performing one fundamental after another, with or without feet bounces between them.
- Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.
- While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
- Avoid bouncing when tired. Keep turns short.
- Properly secure the trampoline when not in use. Protect it against unauthorized use. If a trampoline ladder is used, the supervisor should remove it from the trampoline when leaving the area to prevent unsupervised access by children under six years of age.
- Do not use the trampoline while under the influence of alcohol or drugs.
- For additional information concerning the trampoline equipment, contact the manufacturer.
- For information concerning skill training, contact a certified trampoline instructor.
- Bounce only when the surface of the bed is dry. Wind or air movement should be calm to gentle. The trampoline must not be used in gusty or severe winds.
- Read all instructions before using the trampoline and trampoline enclosure. Warnings and instructions for the care, maintenance, and use of this trampoline and trampoline enclosure are included to promote safe, enjoyable use of this equipment.
- Do not intentionally bounce off the barrier.
- Do not attempt to jump over barrier or attempt to crawl under barrier.
- Do not hang from, kick, cut or climb on barrier.
- Do not attach anything to the barrier that is not manufacturer approved accessory or part of the enclosure system.

Assembly


Step 1

Remove the Wing Nut (6) from the Upper Tube (4). Slide the Cross Tube (8) through two loops sewn to the Mat Surface (1). Then attach the Cross Tube (8) by placing the M10X55mm Bolts (9) through the slots to the Upper Tubes (4).




Step 2

Attach the C Bracket (7) to the Cross Tube (8) with two Wing Nuts (6).
Note: Do not tighten the Wing Nuts (6).




Step 3

Assemble the bottom of the slide by inserting Left and Right Lower Tube (2) into Bent Tube (3) as shown. Adjust the tubes as necessary to ensure that the buttons located at the end of Left and Right Lower Tube (2) pop through the corresponding holes in Bent Tube (3).



Step 4

Open the Ramp Slide and lay on a flat surface or ground with the bent tube (3) up in the air. Position the opening of the ramp mat material over the open joint of rail tubes (4) (2). The upper and Lower tubes have a swage fit that the two tubes sleeve together. Slide the upper and lower tubes together and check they are fully seated together.



NOTICE THIS SLIDE CAN BE FOLDED UP AND SECURED LOOSELY UNDER THE FRAME TO PREVENT UNAUTHORIZED USE BY YOUNGER CHILDREN. WHEN NOT IN USE PLEASE LEAVE THE RAMP SLIDE FOLDED IN THE STORAGE POSITION AS SHOWN NEXT IN STEP 4.


Step 5

To put in the storage position, and to prevent unwanted access to the jumping surface, pull the lower slide section from the upper slide section and fold it over the upper section as pictured. Use the hook and looped straps to secure.




Step 6

To install the assembled slide on your trampoline, align the slide with the opening of your trampoline enclosure net, if applicable. Remove Wing Nuts (6), open C Brackets (7), then lift your spring pad to place the open C Brackets over your trampoline frame. Now it is time for you to tighten Wing Nuts (6) to M10X55mm Bolts (9), securing the slide to the trampoline frame. Next, locate the three straps sewn to end of Slide Surface (1), and tie the straps tightly to the v-rings of your trampoline mat. Tighten all the Nuts.




Step 7

Finally, lower your trampoline spring pad so that it lays over the top of the Slide Surface (1). Adjust your spring pad as necessary to ensure that the top of the Slide Surface (1) is fully covered by the spring pad.



Exploded Drawing and Part List—Model No. 200071

Key No.	Qty.	Description
1	1	Mat Surface
2-1	2	Left Lower Tube
2-2	2	Rgiht Lower Tube
3	1	Bent Tube
4	2	Upper Tube
5	2	Bungee
6	2	Wing Nut
7	2	C Bracket
8	1	Cross Tube
9	2	M10X55mm Bolt
10	2	End Cap
11	2	Ring



LIMITED WARRANTY

Outdoor Product Technologies, Inc (OPT) warrants its trampoline products to be free from defects in material and workmanship under normal use and service conditions. Damage due to Weather or Acts of God is not warranted by Outdoor Product Technologies, Inc (OPT). The steel frame is warranted for one (1) year after the date of purchase. All other parts are warranted for ninety (90) days after the date of purchase.

All warranty coverage extends only to the original retail purchaser from the date of purchase. OPT'S obligation under this Warranty is limited to replacing or repairing, at OPT'S option, the product at one of its authorized service centers. All products for which a warranty claim is made must be received by OPT at one of its authorized service centers, freight prepaid, and accompanied by sufficient proof of purchase. All returns must be preauthorized by OPT.

This Warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repairs not provided by aOPT authorized service center, or to products used for commercial or rental purposes.No other Warranty beyond that specifically set forth above is authorized by OPT.

OPT IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION, WEATHER/ENVIROMENTAL RELATED DAMAGE OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. This warranty gives you specific legal rights. You may also have other rights which vary from state to state. THIS WARRANTY IS VALID ONLY IN THE UNITED STATES.