


IMPORTANT INSTRUCTIONS TO OPEN YOUR CASH BOX!

- ★ Your cash box has it's own special code. This code can be found on the tag attached to the handle.
- ★ The dial MUST be on this number to open the box!!
- ★ Once the dial is on this number, push DOWN (not in) on the silver button. The lid will pop open.



Install Handle using a Screwdriver