

MB3042 - FRONT HALF DOORS


COMPATIBLE WITH JEEP JL/JLU & JT GLADIATOR





ASSEMBLY INSTRUCTIONS




CONTENTS











BAG LABELED AS MB3042-KIT01






MB3064-JLT Hinge, Upper Driver Qty 1



5/16"-18 UNC x 1.00" Long Qty 8



MB3064-JLB

Qty 1

Hinge, Lower Driver

MB3064-JLB_MIR
Hinge, Lower Passenger

Qty 1


Flat Washer, Stainless 5/16" Qty 16



Nylock Nut, Stainless 5/16" UNC Qty 8




CONTENTS






5/16" Qty 2

5/16"-18 UNC Qty 2







CONTENTS













BAG LABELED AS

MB3042-KIT02






















ASSEMBLY - STEP 7



BAG LABELED AS

MB3042-KIT03



ASSEMBLY - STEP 8

FINAL ASSEMBLY & ADJUSTMENT

- 1. Ensure hinge bolts are loose
- 2. Place assembled half door on vehicle door hinges
- 3. Close the door & view the door from the side of the vehicle
- 4. Adjust the door to ensure there is an even reveal & gaps from left to right & top to bottom
- 5. With the door remaining closed, tighten the hinges bolts
- 6. Open the door & adjust the rotary latch fasteners as well as the rubber bumper so that the door latches smoothly & the door sits flush with the outer body

