


MB3043 - REAR HALF DOORS


COMPATIBLE WITH JEEP JL/JLU & JT GLADIATOR





ASSEMBLY INSTRUCTIONS














BAG LABELED AS MB3043-KIT01





Round Head Screw, Stainless 5/16"-18 UNC x 1.00" Long Qty 8

MB3064-JLT Hinge, Upper Driver Qty 1

MB3064-JLT_MIR Hinge, Upper Passenger Qty 1





MB3064-JLB

Qty 1

Hinge, Lower Driver

MB3064-JLB_MIR Hinge, Lower Passenger Qty 1


Flat Washer, Stainless 5/16" Qty 16




Nylock Nut, Stainless 5/16" UNC Qty 8



CONTENTS




Carriage Bolt 5/16"-18 UNC x 3/4" Long Qty 2 Flat Washer, Stainless 5/16" Qty 2 Nylock Nut, Stainless 5/16"-18 UNC Qty 2






CONTENTS






ASSEMBLY - STEP 1







ASSEMBLY - STEP 2















ASSEMBLY - STEP 5



BAG LABELED AS MB3043-KIT03




ASSEMBLY - STEP 6





ASSEMBLY - STEP 7



BAG LABELED AS

MB3043-KIT03



ASSEMBLY - STEP 8

FINAL ASSEMBLY & ADJUSTMENT

1. Ensure hinge bolts are loose

12

- 2. Place assembled half door on vehicle door hinges
- 3. Close the door & view the door from the side of the vehicle
- 4. Adjust the door to ensure there is an even reveal & gaps from left to right & top to bottom
- 5. With the door remaining closed, tighten the hinges bolts
- 6. Open the door & adjust the rotary latch fasteners as well as the rubber bumper so that the door latches smoothly & the door sits flush with the outer body

