

Description of *Camera Wings*

There are 2 type of wings:

1. Freely Wings

Sewn at front of the jacket, this wing is available in 4 sizes:


- **Small:** Fixed
- **Medium:** Fixed or with RSL attachment (RSL metal or plastic)
- **Large:** RSL attachment (RSL metal or plastic)
- **X-large:** RSL attachment (RSL metal or plastic)

2. RW Wings

Sewn on the seam underneath the arm, this wing is available in 4 sizes:

- **Small:** Fixed
- **Medium:** Fixed or with RSL attachment (RSL metal or plastic)
- **Large:** RSL attachment (RSL metal or plastic)
- **X-large:** RSL attachment (RSL metal or plastic)

How to measure



With your rig on, extend your arm as illustrated and take the measurement from armpit to the side strap, as shown on the right illustration.

This measurement is usually between 8" to 11.5"