



BE PROTECTED IN MINUTES

FireAvert is plug-n-play ready. Simply plug into the chosen appliance and sync it to the closest smoke alarm. FireAvert is activated by the smoke alarm, cutting power to the appliance when the smoke alarm is sounding. FireAvert helps mitigate your risk of having a fire. [See video below.](#)

FEATURES

- No batteries and maintenance free.
- No professional install needed.
- Fits behind almost all appliances.
- Reusable with a 25 year expected life.
- Resets at the electrical panel.
- Audible indication of sync with smoke alarm.
- Light indicates number of times activated.
- Sound detection of smoke alarm from up to 60 feet away.



110 V APPLIANCES FA-E03-5-15

INSTALLATION PROCESS

FireAvert is plug-n-play ready. Simply plug into the chosen appliance and sync it to the closest smoke alarm. FireAvert is activated by the smoke alarm, cutting power to the appliance when the smoke alarm is sounding. To reset the appliance after it cuts off power simply unplug the FireAvert and then plug it back or, or flip the associated breaker off and then back on again. This will enable the appliance to begin working again.

SEE HOW EASY IT IS TO INSTALL



ELECTRICAL SPECIFICATIONS

Operating Voltage	120v
Amperage	12.5 amps 60Hz
Plug Configuration	NEMA 5-15 R/P
Pole	2
Wire	3 wire grounding
Fire Rating	Housing ABS fire retardant - UL94(5Va,V-0,V-1,V-2,HB)

PHYSICAL SPECIFICATIONS

Dimensions	3 ¾ inches (9.52 cm) x 2 inches (5.08 cm) x 3 ¾ inches (9.52 cm) – (LxWxH)
Weight	.9 LB (0.408 Kg)
Metal Valve Weight	.9 LB (0.408 Kg)
Color	Black
Operating Temperature Range	32°F to 90°F (0°C to 33°C)
Operating Humidity Range	0 to 80% RH non-compensating
Mounting	None required. Plugs directly into NEMA 5-15R outlet for electrical
Environmental	RY PB Free

LED MODES

LED Mode	Green LED	Red LED	Speaker
Power Up	Solid Green LED	Intermittent Red Flash	Extended Chirping followed by Intermittent Chirping
Pairing	Solid Green LED	Blinks Red	Off Once Synced
Standby	Solid Green LED	Off	Off
Protection Mode	Off	Solid	Off

WARRANTY

[CLICK HERE](#) to download the FireAvert Warranty