Geberit AquaClean app

Operating the shower toilet using the app

The following shower toilet functions can be executed via the Geberit AquaClean app:

• remote control of the Geberit AquaClean shower toilet

• adjustment of the device settings

The Geberit AquaClean app offers the following additional benefits:

• saving your personal settings on your smartphone

• support for care and maintenance of the device

• easy registration of your Geberit AquaClean shower toilet

• function films

• service and contact information

The Geberit AquaClean app is available free of charge for Android and iOS smartphones in the respective app stores.

iOS: Android:

GEBERIT AQUACLEAN SELA
QUICK GUIDE

DOWNLOAD THE APP AND REAP THE REWARDS
www.geberit-aquaclean.com

What you need for cleaning

Selecting suitable cleaning agents and cleaning equipment

The Geberit AquaClean cleaning set (art. no. 242.547.00.1) includes a ready-made cleaning agent that is optimal for cleaning all Geberit AquaClean surfaces.

⚠️ **CAUTION**
Cleaning with aggressive descaling and cleaning agents can cause surface damage.
• Only use Geberit AquaClean descaling agent in the device.
• Only use cleaning agents permitted by Geberit.

Geberit AquaClean consumables

Geberit AquaClean cleaning set (art. no. 242.547.00.1)

Geberit AquaClean descaling agent (art. no. 147.040.00.1)

Permissible cleaning agents

Only skin-friendly cleaning agents

Only liquid cleaning agents

Preferably water-diluted cleaning agents

Cleaning agents with a low acid content (e.g. heavily diluted citric acid)

Mildly foaming cleaning agents

Permissible cleaning equipment

Soft, fine-pored sponges

Lint-free, soft cloths which are free of dust

Toilet brush

The device at a glance

Geberit AquaClean Sela

1 WC lid
2 Remote control with magnetic wall-mounted holder
3 WC seat ring
4 Spray arm with spray nozzle and Lady shower nozzle

Assigning the remote control

Switch on the device, then press and hold the <+> button on the remote control for approximately 30 seconds until <Pairing ok> appears on the rear display.

The remote control at a glance

Front side of the remote control

All functions for daily use can be operated from the front side of the remote control.

1 <Shower> button
2 <–>/<+> buttons
3 <left>/<right> arrow keys
4 <Lady shower> button
5 <Oscillating motion> button
6 <Orientation light> button
7 User profile buttons

> ℹ User profiles allow you to access your personal settings directly. You can save 4 user profiles.

Rear side of the remote control

Individual functions can be selected from the rear side of the remote control.

1 Battery compartment
2 LCD display
3 <up>/<down>, <left>/<right> arrow keys

How to use the device

Using the anal shower

Press the <Shower> button once to switch on the anal shower.

> ℹ Press the <Shower> button again to stop the shower procedure early.

Setting the spray intensity

Press the <+> button to increase the spray intensity in stages.

Press the <–> button to decrease the spray intensity in stages.

> ℹ You can set the spray intensity in 5 stages.

Setting the spray arm position

Press the arrow keys to position the spray arm.

> ℹ You can set the spray arm position in 5 stages.

## Using the Lady shower

Press the <Lady shower> button once to switch on the Lady shower.

> ℹ Press the <Lady shower> button again to stop the shower procedure early.

Switching on the oscillating motion

Press the <Oscillating motion> button to start the oscillating motion of the anal shower.

> ℹ Press the <Oscillating motion> button again to switch off the oscillating spray early.

Switching on the orientation light

Press the <Orientation light> button to switch on the orientation light.

> ℹ Press the <Orientation light> button again to switch off the orientation light.

Saving user profiles

Press and hold one of the user profile buttons for 2 seconds to save the current settings as the user profile for this button.

> ℹ Press the user profile button again to activate your user profile.