
## **SOHO 52**





# Caution


**GB>Please** only clean with a duster or a damp cloth. Do no use any abrasive cleaners.


Dear customer, should there be any plece missing or damaged, kindly mark this piece clearly on the attached assembly instructions and return them to us.


# Service Card


### **ACCESSORIES**


8.0x30	4.0x27		Ø15x12		_	4.0x30	
	G					Manual (4)	
D	₿ G	A	ဳ 🖤 B	x	ZA	. Р	S
8	2	8	8	8	2	4	8
Von.				4.0x16		Ø 5.0	Ø 8.0
			7	<b>△ⅢⅢ</b> (†)		(4)	0
KR	l	L		H2	F	X4	X3
2	6	2	2	8	1	4	2























### GUIDLINES FOR FURNITURE USE AND MAINTENANCE

#### GB

- 1. Furniture should be used in rooms which are dry and protected against the harmful influences of weather conditions.
- 2. Furniture should be assembled in accordance with the assembly manual.
- 3. Furniture should be assembled as close as possible to it's intended final location.
- 4. While positioning the furniture make sure it is levelled
- 5.Furniture may be moved only by lifting and carrying it over when emptied of its contents. Pusching it over or pulling it along may ruin the

furniture permanently. While carrying the furniture over it must be held by its vertical elements, i.e side panels or legs. Furniture cannot be

held by it's horizontal elements prone to destruction, i.e desktops drawer, etc..

- 6.furniture should not be overloaded as this may ruin it permanently.
- 7. While using the furniture, the state of the connections between it's elements should be checked if necessary.
- 8.furniture surface must be cleaned only with furniture maintenance formulas.

