Quick Start Guide

litter·robot[®]







Never push the Litter-Robot against a wall or into a corner (must not be touching any walls).

Cats must weigh at least 5 lbs. to safely use the Litter-Robot in Automatic Mode.



experience and tips on acclimating your cat, please scan the QR code or visit litter-robot.com/gettingstarted



- If possible, place the Litter-Robot in the same location as the old litter box (at least during transition).
- Make sure the unit is indoors on a firm, level surface and in a cool, dry location.
- Place litter mats or rugs in front of, or completely under, the unit. Do not place mats partially under the unit. Use only low pile (1/4 inch) mats or rugs under the unit.



- Use clumping litter or litter beads and crystals that are small enough to pass through the screen.
- Add litter until it meets the raised fill line when spread flat (about 8-10 pounds). Be careful not to overfill.





Insert the small plug end of the power cord into the socket on the back of the base. Plug the AC/DC adapter into a wall outlet.

Press the Power button on the control panel.

4 Download The App

Litter-Robot Connect units only – look for the WiFi symbol on the control panel. Download the AutoPets Connect app and follow the onboarding instructions.

The Litter-Robot will now perform an initial clean cycle.

Need help? Visit litter-robot.com/help