


11/30/2020

DROPSET 5 - UPPER BEARING FIT CHECK
(Dimensions in mm)

DROPSET 5 UPPER BEARING ϕ :
42MM (41.8mm actual)



METHOD A

- 1) Disassemble the headset and remove the existing upper bearing
- 2) Use the depth blade on a pair of calipers (set to mm), and measure from the top of the headtube to the corner where the 45° taper starts

METHOD B

- 1) Disassemble the headset leaving the existing upper bearing in place
- 2) Use the depth blade on a pair of calipers (set to mm), and measure from the top of the headtube to the top of the existing upper bearing

*Method B is easier to measure and provides more accuracy

SECTION VIEW OF HEADTUBE AND BEARING