



Change the way you think about time

CONSOLE

INSTRUCTION MANUAL

USB Port




Button A



Button B


1. How to read the time

- Press button A to display the time.
- All LEDs will light up and the time will be shown.
- The current time is indicated by the blinking LEDs.
- The time display will turn off after 7 seconds.



Examples

3:06



3 o'clock light is flashing
5 minute light is flashing
1 minute light is flashing

8:32



8 o'clock light is flashing
30 minute light is flashing
2 minute lights are flashing

2. How to set the time and animation

- Press and hold button B for 3 seconds to enter setting mode.
*Note after 7 seconds of inactivity setting mode will deactivate

i. Setting the hour

- The hour LEDs will flash when you are in hour setting mode.
- Press button A to increase the hours as required.
- The PM indicator will flash to indicate PM mode.
- Press button B to confirm and move to the minutes.

PM / Charging indicator



ii. Setting the minutes

- The minute LEDs will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Press button B to confirm and move to the animation.

iii. Setting the animation

* This watch has a light-up animation feature. The LEDs will animate once every 15 minutes between 6pm and 12am.

- In setting mode, when the animation feature is on, the LEDs will animate.
- In setting mode, when the animation feature is off, all LEDs will flash.
- Press button A to turn the animation on or off.
- Press button B to confirm and when the LEDs go out, setting is complete.

*Note after 7 seconds of inactivity setting mode will deactivate

3. How to recharge the battery

- This watch has a USB rechargeable battery.
- When the lights become dim or do not light up, you should recharge the battery.
- To recharge the battery, unscrew the USB cap using the screw driver provided and connect the USB charging cable to the USB charging jack.
- Connect the charging cable to a power source, e.g. your computer.
- When charging, the LED charging indicator will blink.
- When the charging indicator stops blinking, the battery is 90% charged.

It is advised that you continue to charge the battery for a full 3.5 hours to ensure the battery is 100% charged.

PM / Charging indicator



- It is advised that you use the screw driver provided when opening the USB cap so as not to damage the head of the screw.

4. Items included in the box



- Watch
- USB cable
- Spare USB cap
- Screw Driver
- Instruction Manual



5. Battery

- This watch uses an LIR 2032 rechargeable battery only.
- The LIR 2032 rechargeable battery is replaceable.
- Battery lifetime will vary depending on use, but is estimated at approximately 300 charges.
- To maximize battery life, turn the animation off.
- The plug standard input voltage for the LIR 2032 battery is DC5V. You should use only the cable provided with the watch when recharging.

6. Caution

- This watch is water resistant to 3ATM.
3ATM means suitable for everyday use to resist splashes of water & rain. 3ATM does not cover swimming, diving or other water related activities.

7. Warranty

- This watch is covered by a 1 year manufacturers warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

SPECIFICATIONS

Case Materials	Acetate
Strap Materials	Acetate
Case Dimensions	59 x 30 x 12 mm
Finish	Glossy
Maximum Fit Wrist Size	210mm (approx.)
Weight	82g
Display	LED
Battery	LIR 2032
Water Resistance	3ATM

