



PRODUCTS


Designed in JAPAN

MODEL 2

TOKYOFASH JAPAN®

CHANGE THE WAY YOU THINK ABOUT TIME

www.tokyoflash.com



1. HOW TO READ THE TIME

- This watch uses Nixie tubes to display the time using the 24 hour clock.
- The time is read like a digital watch. Press button A to illuminate the display.
- The time in hours and minutes is shown in 3 cycles for a total of 5 seconds: hour - minutes - hour - minutes - hour - minutes.
- When the time is shown, press button A and the display will show the progression of seconds for 5 seconds.

EXAMPLE:



2. HOW TO SET THE TIME

- Press button B to enter setting mode (please use a pointed tool).
- The display will flash the current hour and the hour indicator will light up.
- Press button A to change the hour.
- Press button B to confirm and move to minutes setting.
- The display will flash the current minutes and the minute indicator will light up.
- Press button A to change the minutes.
- After 10 seconds the watch will exit setting mode.

3. HOW TO CHARGE THE WATCH

- When the Nixie tubes no longer light up, or if only the hour and minute indicators light up, or if you have not used the watch for 2 months, you should recharge the watch.
- The watch can be recharged by connecting the USB charging cable provided to the watch USB port and to your computer's USB port.
- To open the watch USB port, use the screw driver included with the watch so as not to damage the screw head.
- Only use the USB cable provided to recharge the watch because it is designed for this watch.
- When charging, the blue LEDs will flash. When the blue LEDs stop flashing, the watch is fully charged.
- It is advised that you charge the watch for 1-1.5 hours to ensure the battery is 100% charged.
- Charging the watch for longer than 1.5 hours will not increase battery life.

4. NIXIE TUBE IONIZATION DELAY

- Sometimes the watch might experience a delay in lighting up. This is normal. It is because the Nixie tubes sometimes need time to ionize and wake up. After waking up, the Nixie tubes will become fully active again.

5. BATTERY

- This watch uses a 3.7V PL401030 rechargeable battery.
- Based on typical use, the battery should last for 1 month between charges.
- The battery lifetime is expected to be at least 100 charges.
- Only use the USB cable provided to recharge the watch because it is designed for this watch.
- This watch must only be returned to our service center for battery replacement.
- Please do not open the case back of this watch to change the battery. As explained in point 6, this will void the warranty.

6. INCLUDED IN THE BOX

- Watch
- USB cable
- Screw driver
- Spare USB screw
- User manual

7. WARRANTY

- This watch is covered by a 2 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair. Replacement Nixie tubes are not covered by this warranty.
- Please do not open the case back of this watch. There is a paper warranty seal inside and if this seal is broken the warranty will become void and our service center will not accept the watch for repair.

8. WATER RESISTANCE

- This watch has limited water resistance. Please do not use the watch in the shower, for swimming or for other water related activities.

9. SPECIFICATIONS

| | |
|----------------------|--|
| Display: | Soviet made IN-16 Nixie tubes / blue LEDs |
| Nixie Tube Lifetime: | 200k hours (more than 20 years) |
| Case Material: | Brass |
| Strap Material: | Leather or Stainless Steel |
| Case Dimensions: | 59 mm x 59 mm x 17 mm |
| Finish: | Sandblasted black or silver / unique 'aged' brushed IP brass or bronze |
| Wrist Size: | Approx. 160 mm - 220 mm (adjustable) |
| Weight: | 130-210 grams (depending on strap option) |
| Battery: | 3.7V PL401030 rechargeable battery |

Tokyoflash Japan

Change the way you think about time
watches@tokyoflash.com