


# ROTAIR

TOKYOFLASH JAPAN®

change the way you think about time

[www.tokyoflash.com](http://www.tokyoflash.com)



## 1. HOW TO READ THE TIME

This watch uses revolving discs to show the time.

- The time in hours and minutes is shown horizontally by the numbers in the center of each disc.



Time: 9:30



Time: 12:45



Time: 6:15

## 2. HOW TO SET THE TIME

- Press and hold button C for 2 seconds to enter setting mode.
- Press button C to change the hour as required.
- Press button B to change the group of 10 minutes as required.
- Press button A to change the single minutes as required.
- Press button D to confirm and exit setting mode.

## 3. DISC REVOLUTION FEATURE

- You can initiate a revolution of the discs by pressing button A.

## 4. POWER SAVING MODE

- To minimize power consumption when not using the watch you can activate power saving mode.
- Press button B three times.
- The discs will revolve and stop at 12:00.
- To deactivate power saving mode, press any button and the discs will revolve to show the time.

## 5. DISC CALIBRATION MODE

- If the discs do not stop in the correct position, you can calibrate their position.
- Press and hold button D for 3 seconds to enter calibration mode.
- Press or hold button C to adjust the position of the hour disc to 12.
- Press or hold button B to adjust the position of the groups of 10 minutes disc to 0.
- Press or hold button A to adjust the position of the single minutes disc to 0.
- Press button D to confirm and exit disc calibration mode.
- Set the time (point 2 above).

## 6. BATTERY

- This watch uses 2 x LR44 (or AG13) standard replaceable watch batteries.
- Battery lifetime will vary depending on use but is estimated to last for at least 1 year.
- To maximise battery life, when not using the watch you should activate power saving mode (point 4 above).
- If you notice the discs not moving correctly or not moving at all it is advised that you change the batteries.

## 7. WARRANTY

- This watch is covered by a 2 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

## 8. WATER RESISTANCE

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

## 9. SPECIFICATIONS

Display:	Revolving disc display
Case Material:	Alloy
Strap Material:	Leather
Case Dimensions:	44 mm x 41.6 mm x 14.4 mm
Finish:	Polished & brushed IP black, bronze, gold, silver
Wrist Size:	Approx. 150 mm - 220 mm (adjustable)
Weight:	88 grams
Battery:	2 x LR44 (or AG13) standard replaceable watch batteries
Water Resistance:	3ATM

Tokyoflash Japan  
change the way you think about time

[watches@tokyoflash.com](mailto:watches@tokyoflash.com)