

RPM

Instruction Manual

USB Charging
Jack



 KISAI

1. How to read the time

- Press button A to display the time.
- All LEDs will light up and the time will be shown.
- The current time is indicated by the blinking LEDs.
- The time display will turn off after 7 seconds.



Hours: 1-12

Minutes: Groups of 5
5, 10, 15, 20, etc



Minutes: 1-4



PM / Charging indicator



Examples

3:49



3 o'clock light is flashing
45 minute light is flashing
4 minute lights are flashing

6:06



6 o'clock light is flashing
5 minute light is flashing
1 minute light is flashing

2. How to set the time and animation

- Press and hold button B for 3 seconds to enter setting mode.

Note after 7 seconds of inactivity setting mode will deactivate

i. Setting the hour

- The hour LEDs will flash when you are in hour setting mode.
- Press button A to increase the hours as required.
- The PM indicator will flash to indicate PM mode.
- Press button B to confirm and move to the minutes.

PM / Charging indicator



ii. Setting the minutes

- The minute LEDs will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Press button B to confirm and move to the animation.

iii. Setting the animation

* This watch has a light-up animation feature. The LEDs will animate once every 15 minutes between 6pm and 12am.

- In setting mode, when the animation feature is on, the LEDs will animate.
- In setting mode, when the animation feature is off, all LEDs will flash.
- Press button A to turn the animation on or off.
- Press button B to confirm and when the LEDs go out, setting is complete.

Note after 7 seconds of inactivity setting mode will deactivate

3. How to recharge the battery

- This watch has a USB rechargeable battery.
- When the lights become dim or do not light up, you should recharge the battery.
- To recharge the battery, unscrew the USB cap using the screw driver provided and connect the USB charging cable to the USB charging jack.
- Connect the charging cable to a power source, e.g. your computer.
- When charging, the LED charging indicator will blink.
- When the charging indicator stops blinking, the battery is 90% charged.

It is advised that you continue to charge the battery for a full 3.5 hours to ensure the battery is 100% charged.

PM / Charging indicator



- It is advised that you use the screw driver provided when opening the USB cap so as not to damage the head of the screw.

4. Items included in the box



- Watch
- USB cable
- Spare USB cap
- Screwdriver
- Instruction Manual



5. Battery

- This watch uses an LIR 2032 rechargeable battery only.
- The LIR 2032 rechargeable battery is replaceable.
- Battery lifetime will vary depending on use, but is estimated at approximately 300 charges.
- To maximize battery life, turn the animation off.
- The plug standard input voltage for the LIR 2032 battery is DC5V. You should use only the cable provided with the watch when recharging.

6. Warranty

- This watch is covered by a 1 year manufacturers warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

RPM

取り扱い説明書

充電用
USBジャック



 KISAI

1. 時刻の読み方

- Aボタンを押すと時刻表示がスタートします。
- 全てのLEDが点灯し時刻を表示します。
- LEDが点滅した箇所が現在時刻です。
- 時刻表示は7秒後自動的に終了します。



時: 1-12

5分単位

5, 10, 15, 20, etc



1分単位: 1-4



充電中 / PM




時刻表示例

3:49



3時のLEDが点滅
45分のLEDが点滅
4分のLEDが点滅

6:06



6時のLEDが点滅
5分のLEDが点滅
1分のLEDが点滅

2. 時刻・アニメーションの設定

- Bボタンを3秒間押し続けると設定モードになります。

※7秒間何も操作をおこなわないと、設定モードは自動的に終了します。

i. 「時」の設定

- 「時」の設定時は、時間表示のLEDのみが点滅します。
- Aボタンで1時間ずつ増やすことができます。
- PM時間帯の設定時にはPMインジケーターが点滅します。
- Bボタンを押すと確定して次の「分」の設定に移動します。

充電中 / PM



ii. 「分」の設定

- 「分」の設定時は、分表示のLEDのみが点滅します。
- Aボタンで1分ずつ増やすことができます。
- Bボタンを押すと確定して次の「アニメーション」の設定に移動します。

iii. 「アニメーション」の設定

※本品にはLEDによる光のアニメーション表示があります。アニメーションを設定すると、6pmから12amの間、15分ごとに1回アニメーションが表示されます。

- 設定モードでは、アニメーションがONの場合はアニメーションが表示されます。
- また、アニメーションがOFFの場合は全てのLEDが点滅します。
- AボタンでアニメーションのONとOFFの切り替えができます。
- Bボタンを押すと確定してLEDが消灯し、設定モードは終了します。

※7秒間何も操作をおこなわないと、設定モードは自動的に終了します。

3. バッテリーの充電方法

- 本品はUSB充電バッテリーを内蔵しています。
- LEDの輝度が弱くなったり、点灯しなくなった場合は、バッテリーを充電してください。
- 充電する場合は、付属のドライバーでUSBキャップをはずし、USBケーブルをUSBジャックに接続してください。
- USBケーブルの片方の端子をパソコンなどの電源供給が可能なUSBジャックに接続してください。
- 充電中はLEDの充電インジケーターが点滅します。
- バッテリーが90%まで充電されると、ブルーLEDの充電インジケーターが点灯に変わります。100%のフル充電をされる場合は、約3.5時間の連続充電をおこなってください。

充電中 / PM



- USBキャップをはずす場合、ねじを損傷しないように付属のドライバーを使用してください。

4. 付属品



- 本体
- USB ケーブル
- スペア用 USB キャップ
- ドライバー
- 取り扱い説明書



5. バッテリー

- 本品にはLIR 2032充電バッテリーが内蔵されています。
- バッテリーの寿命は使用状況によって異なりますが、およそ300回の充電が可能です。
- アニメーションの設定をOFFにすると、バッテリーの寿命を長くすることができます。
- LIR 2032充電バッテリーは交換可能です。
- LIR 2032充電バッテリーの入力電圧はDC5Vです。充電の際は必ず付属の専用USBケーブルをご使用ください。他のUSBケーブルを使用するとモジュールを破損させる可能性があります。

6. 保証

- 生産時に生じた不良にのみ1年間の無償修理を保証します。不注意による故障、破損、水害等は保証期間内であっても有償修理となりますので、ご了承ください。