


SATELLITE-X

INSTRUCTION MANUAL



..... Button A


..... Button B



Change the way you think about time

1. How to read the time

- Press button A to display the time.
- All LEDs will light up and the time will be shown.
- The current time is indicated by the blinking LEDs.
- The time display will turn off after 7 seconds.



Examples

12:06



12 o'clock light is flashing
5 minute light is flashing
1 minute light is flashing

10:17



10 o'clock light is flashing
15 minute light is flashing
2 minute lights are flashing

2. How to set the time and animation

- Press and hold button B for 3 seconds to enter setting mode.
Note after 7 seconds of inactivity setting mode will deactivate

I. Setting the hour

- The hour LEDs will flash when you are in hour setting mode.
- Press button A to increase the hours as required.
- The PM indicator will flash to indicate PM mode.
- Press button B to confirm and move to the minutes.

PM / Charging Indicator



II. Setting the minutes

- The minute LEDs will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Press button B to confirm and move to the animation.

III. Setting the animation

This watch has a light-up animation feature. The LEDs will animate once every 15 minutes between 6pm and 12am.


- In setting mode, when the animation feature is on, the LEDs will animate.
- In setting mode, when the animation feature is off, all LEDs will flash.
- Press button A to turn the animation on or off.
- Press button B to confirm and when the LEDs go out, setting is complete.

Note after 7 seconds of inactivity setting mode will deactivate

3. How to recharge the battery

- To recharge the battery, connect the USB charging cable provided to the watch USB port and then to a power source, e.g. your computer.
- To open the watch USB port, use the screw driver included.
- When charging, the charging indicator will flash.
- When the charging indicator stops flashing, the watch is 90% charged.
- It is advised that you continue to charge the watch for a full 3.5 hours to ensure the battery is 100% charged.


PM / Charging Indicator



4. Items included in the box

Included in the box

- Watch
- USB cable
- Screw driver
- Spare USB cap
- Watch manual



7. User information

I. Battery

- This watch uses a PL301517 rechargeable watch battery.
- The battery should last about 1 month between charges.
- The battery lifetime is expected to be 300 charges.
- Only use the cable provided with the watch for recharging, as it is designed specifically for this watch.

II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch has limited resistance to water. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

Case Materials	Wood
Strap Materials	Wood
Case Dimensions	32mm x 44mm x 13mm
Finish	Clear Coating
Maximum Fit Wrist Size	210mm (approx.)
Weight	68g
Display	LED Digital Tube
Battery	PL301517