

Kendon Industries, LLC 2990 E. Miraloma Ave., Anaheim, CA 92806

TRAILER CRANK DOWN SWIVEL JACK STAND INSTRUCTIONS

FITS: DUAL, SINGLE, COMBO, TRIKE, UTILITY

*** TO AVOID DAMAGE TO TRAILER REMOVE JACK STAND WHILE TOWING ***

TOOLS REQUIRED: Socket Wrench with 7/8" Socket or Adjustable. Torque Wrench capable of torqueing to 55 ft. lb.

PARTS LIST:

- Swivel Jack Stand with Caster Wheel
 - Swivel Jack Stand Mounting Bracket
 - 5/8" Fender Washer

- 5/8" USS Washer
- 5/8" Split Lock Washer
- 7/16" Shoulder Nut with 7/8" Hex Head

INSTRUCTIONS:

- 1. Remove the existing 7/16" lock nut closest to the back of the coupler on the trailer using a 9/16" wrench or socket.
- 2. Remove the remaining nuts and washers used to secure the safety cable and remove the safety cable.
- 3. Refer to the diagram to the right and position mounting bracket over the bolt welded to the coupler from which the safety cable was removed. (Install bracket on **Rear** bolt furthest from tongue)
- 4. Refer to the diagram to the right and use the included hardware in the following order to secure the mounting bracket: 5/8" USS Washer (large wide washer), then Safety Cable, 5/8" SAE Washer (Smaller washer), 5/8" Split Lock Washer and then 7/16" Shoulder Nut with 7/8" Hex Head.
- 5. Slide the mounting bracket against the bottom side of the coupler and tighten the Shoulder Nut. NOTE: The shoulder nut will pass through the washers and safety cable to attach to the threaded bolt.
- 6. Torque the shoulder nut to 55 ft. lb.
- 7. Refer to the pictures below for the finished installation of the mounting bracket.







