

Fitting the Mobility 56

1

1. Two rails with casters

Fitting the Mobility 56

- 1** To gain access to the base of the IQAir device, carefully lay the IQAir on the floor. Do not place the device onto its side arms. To avoid scratching the IQAir housing, place the device on a soft surface, such as a towel.
- 2** Insert the four casters into the base of the IQAir device by pushing the fitting blocks into the special slots next to the black rubber feet.
- 3** You will hear a clicking sound when the fitting blocks snap into place. Test whether the casters are securely locked in place by gently pulling.
- 4** When all four casters are locked in place, carefully lift the IQAir device and place it on the casters. Two of the casters are lockable. To lock, simply push the lever of the caster down. To release, lift the caster lever.