

FIRST TEAM POP-A-SHOT® PREMIUM ELECTRONIC BASKETBALL GAME ASSEMBLY INSTRUCTIONS


TOOLS REQUIRED:

- Allen Wrench (included)
- 9/16" Open End Wrench
- 7/16" Open End Wrench
- Pliers

1. Thoroughly inspect all parts for quantity and defects..
 2. Raise Front Upright. Insert Bolt into Base.
 3. Raise Back Upright. Attach T-Bar to Back Cross Bar and adjust T-Bar to support the Back Upright. Tighten Bolts and Set Screw.
 4. Insert Support Bars into the Back Uprights and the Front Uprights. Tighten Set Screws.
 5. Attach Rim w/ Collar Assembly to the Backboard. Insert Lead wire's white female Molex end onto the male ends on the back of the Electronic Scoreboard.
 6. Attach Ramp to the 4 Cup Hooks on the lower back of the Backboard.
 7. Using Zip Ties through the grommets, attach the ramp to the back of the game where T-Bar bolts to the frame. Leave slack in the ties to allow for adjustments until after side nets are attached.
 8. Using Zip Ties through the grommets, attach the ramp to the Front lower Cross Bar of the 2 Cross Bars. Leave slack in the ties to allow for adjustments until after side nets are attached.
 9. Pull Vinyl flap over the top Cross Bar and then under the lower Cross Bar. Attach flap to the Velcro underneath the ramp.
 10. Attach the sides of the ramp to the Top Support Bars and along the Back Uprights and the Front Uprights of the game. Make sure All Velcro straps are in place.
 11. To make the ramp taut, adjust the ties on the Back Upright first and then the ties on the Front Uprights. Keep in mind that the ramp should have square corners. Step #8 may have to be repeated. Clip ties when completed.
 12. The optional telescoping legs may be released by removing the positioning bolts from the frame. Lift the Front end first to let the legs drop far enough to reinsert the positioning bolts into the predrilled holes in the legs and the frame. Repeat this step for the back of the game.
 13. Insert the male end of the Power Supply into the Female end located on the back side of the Electronic Scoreboard. Plug into power outlet.
 14. Inflate the 3 Balls.
-

POP-A-SHOT[®] PREMIUM ELECTRONIC BASKETBALL GAME

"AMERICA'S STRONGEST ELECTRONIC BASKETBALL GAME"



- High Front Nets Contain Balls During Play
- EZ Install
- EZ Transport - fold up
- Heavy Duty Steel Frame
- Free Play / Starts with First Made Basket

Ideal For:

- High Traffic Play / Churches
- Home / Recreation
- Premiums / Fund Raisers
- Sales Incentives
- Product Promotion
- Boys / Girls Clubs / Health Clubs
- Point of Purchase Displays
- Gifts & Awards
- Trade Show Visibility
- Bars & Taverns



Specifications:

- **Length:** 8'
- **Width:** 32"
- **Height:** 7' 10" with legs
6' 10" without legs
- **Backboard:** 3/4" particle board
- **Rim Goal:** 3/8" steel
- **Vinyl Ball Return (heavy duty)**
- **Mini Basketballs (3)**
- **Packaging:** One Box - Truck Freight

POP-A-SHOT® STEEL PREMIUM

ELECTRONIC BASKETBALL GAME

