



The Barnacle Vibe

100% WATERPROOF SPEAKER

Powered By:  SPEAQUA

U S E R M A N U A L



The Barnacle Vibe

100% WATERPROOF SPEAKER

Powered By: **SPEAQUA**

Built with purpose- our team has mindfully incorporated various rad & unique features that we think you can all appreciate. We are sure you will be able to figure out how to use this speaker without reading these directions, but incase you get a bit lost, take a quick read.

PACKAGING CONTENTS

Speaker, USB charging cord, User Manual

WARRANTY

6 Months Limited Warranty. Please contact GILI at www.gilisports.com/pages/contact-us for warranty requests.

CHARGING

Charging The Barnacle Vibe is real easy. We have enclosed a USB charging cord, which you can plug into a wall outlet or your computer. The battery is re-chargeable, and allows for up to 8 hours of jamming.

- Wall outlet- you will need to find a power cord with a micro USB or a USB AC adapter. This includes the one typically used for your cell phone.
- Computer- simply plug the USB end of the cord into your computer.

THE VIBE BUTTON CONTROL



PREVIOUS SONG

- Tap to select the previous song.



PLAY/PAUSE




- Tap to "Play/Pause" Music
- Long press (2s) to connect or disconnect Bluetooth Mode.
- **PHONE CALLS**: tap to pick up or hang up an incoming call. Long press (2s) to reject an incoming call/return to your music.



NEXT SONG

- Tap to select next song.
- **DUAL PAIRING**: long press (2s) on primary speaker to enter and exit dual pairing mode (indicated by voice prompt "dual pairing" and alternating blue and white LED on primary speaker; a **white** light will show on the secondary speaker after connected).


LIGHT LED INDICATORS

-  BLUETOOTH
-  TWS. DUAL PAIRING
-  MEMORY



BATTERY CHARGING RED LIGHT

- While charging: **Slow Blinking**=Charging, **Solid**=fully charged
- While not charging: **Fast Blinking**= less than 15% battery.



VOLUME UP

- Tap to increase volume.
- Hold to continuously increase volume.



POWER/MEMORY MODE

- Tap to turn on.
- Long press (2s) to power off.
- **MEMORY MODE**: while powered on tap once to switch to Memory Mode. Tapping this button switches you between Bluetooth Mode (indicated by a **blue** light) and memory mode (indicated by a **green** light).



VOLUME DOWN

- Tap to decrease volume.
- Hold to continuously decrease volume.

CHARGING PORT/COMPUTER PLUG IN

- Insert micro USB data cable into here.
- Make sure the flap is always secured when using the speaker in water.
- Plug in here and connect to computer to drag and drop songs onto the "Barnacle V" folder.
- Make sure to safely eject.

BUILT-IN FEATURES

UNIVERSAL MOUNTING

BUILT-IN CLIP + 1/4" THREADED SCREW

Stick it. Hang it. Fasten it. Designed for true portable outdoor performance, The Barnacle Vibe offers unprecedented versatility with its tool-free mounting options. 1/4" thread secures the speaker to any universal camera mount, while the metal hanger offers up convenient on-the-go attachment and hanging options.



BUILT-IN CLIP

1/4" THREADED SCREW



REMOVABLE SUCTION

STICK IT . RIP IT

More Options. industrial strength suction sticks to any smooth surface. While not in use, users can now unscrew the attachment for an updated and intriguingly simple design.



ACTION CAMERA GO PRO ADAPTER

Package includes a go pro adapter to safely mount the speaker to your SUP. The threaded nut allows you to point your speaker in any direction.

WHAT IS FUNCTIONALLY WATERPROOF?

The ability to function and continuously play music IN, AROUND, AND UNDER water independent of a smart device.



NO PHONE NEEDED

NO MORE. Being Tethered to your phone or water damage



UNINTERRUPTED PLAY

NO MORE. Bluetooth disconnecting when submersed. Continuous (& audible) underwater play.



SAVES BATTERY LIFE

NO MORE. Draining your phone's battery life or streaming data.

MEMORY BUTTON CONFIGURATIONS

-Bluetooth Mode automatically activates when powering on The Barnacle Vibe. Bluetooth Mode is indicated by a blinking **blue light**.

-To switch to Memory Mode simply tap the power button. Memory Mode is indicated by a **green light**.

DOWNLOADING MUSIC ONTO THE DEVICE

Step 1. Enclosed in this package is a micro USB data cable. Begin by **POWERING ON** The Barnacle Vibe . Plugging the micr USB cord into the charging port of the speaker and the USB side into your computer.

Step 2. A folder will then appear named "**Barnacle V**". Drag and drop your music into the "Barnacle V" folder. Add songs in the order you want them to play. To completely remove songs from the device, drag them out of the folder into your computer's trash bin and empty the bin before ejecting.

Step 3. Disconnect by safely ejecting the USB from the computer.

HOW TO PAIR TWO SPEAKERS (WIRELESS DUAL PAIRING)

Step 1. Make sure both VIBE speakers ([Speaker A](#) and [Speaker B](#)) are on and in close proximity to each other. [Speaker A](#) may or may not be connected to your smart device. However, [Speaker B](#) must not be paired to a smart device and must be in Bluetooth pairing mode. To enter BT pairing mode, press and hold the “play/pause” key for 2 seconds. This is indicated by a blinking blue light.

Step 2. Press and hold the “Next” button for 2 seconds on [Speaker A](#). You will then hear the voice prompt: “Dual Pairing” on [Speaker A](#). This is indicated by a flashing “blue and white” light on [Speaker A](#).

Step 3. The two speakers will then pair together. [Speaker A](#) will turn to a blue LED light. [Speaker B](#) will turn to a solid “white” light to indicate that the two speakers are paired.

Step 4. If you have already paired via Bluetooth to [Speaker A](#), your music will begin playing on both speakers. If you have not, please connect via Bluetooth to [Speaker A](#) to begin playing your music.

BLUETOOTH CONNECTIVITY: TURN ON & TUNE IN

You guys should be frothing on Bluetooth technology. No wires, no worries. Our Bluetooth range allows your device to be as far as 10 meters (33 feet) away.

HOW BLUETOOTH TECHNOLOGY WORKS?

Naturally, you will have to use a smart phone, tablet, or computer that has Bluetooth capabilities.

- 1) Once you bring your Barnacle Vibe to life, you will see a blinking [blue light](#). This light means you're ready to connect.
- 2) You will then have to search the Bluetooth settings on your device for “**Barnacle Vibe**”. Select and connect- then you are cruising.
- 3) You should only have to do this once. As long as the speaker and your device have Bluetooth turned on, they will automatically connect.

Note: in order to cut off the Bluetooth connection, give the play/pause button a couple second hold down. There will be a sound to notify you that the connection has been disabled.

SPEAKERPHONE

As if you were not on your phone enough, we made it possible to take hands free calls using The Barnacle Vibe. We have found this to be real useful for not missing a call while in the shower. We also encourage you to put down your cell phone while in the car.

HOW THE SPEAKERPHONE WORKS?

- When receiving a phone call, your music will be paused.
- Tap the Play/Pause button to both answer and hang up the call. If you just are not too keen on answering that certain someone's phone call, you can hold down the Play/Pause button for 2 seconds and the call will be ignored.
- Once you hang up/dismiss the call, your song will resume.

WATERPROOF/DUSTPROOF: IP68

What does IP68 mean?

IP stands for ingress protection. The IP system is a solid particle protection and water protection grading system. The 1st number is solid particle protection, rated (0-6). The 2nd number is water protection, rated (0-8). We uphold the best rating of solid particle protection (6). This means the speaker is fully dust proof. If you were to place the speaker in a box of talcum powder and stir the powder around for up to eight hours- the dust could not enter the speaker.

Like we said, The Barnacle is a creature of the sea and we designed this creature to endure any aquatic adventure. The Barnacle upholds the highest rating of water protection (8)! - Capable of withstanding full water immersion.

- To be specific, a depth of two meters (6.6 feet) for up to 60 minutes.

Note: We encourage you to bring this speaker with you on all your adventures. Don't be afraid of some sand, mud, snow, or ocean water. For this reason, we have made the speaker real easy to clean. Use fresh water and a soft towel to wipe away dirt/dust.

FCC DISCLAIMER

Note: this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: changes or modifications not expressly approved by Speaqua Corp. could void the user's authority to operate this equipment.

PLEASE USE THIS PRODUCT RESPONSIBLY.

Here are some standard safeguards to follow when using any consumer electronics:

- WARNING: do not place speaker very close to your ears. This may cause damage to your ear drums, particularly in young children.
- For the reason above, please keep away from young children. This is not a toy.
- GILI Sports is not liable for any damage to smartphones, iPods/MP3/M4A
- Keep speaker clear from heated surfaces.
- Use this product for its intended uses described in the manual.
- Do not operate this product if there is any damage to the cord, plug, or housing.