



In reference to the setting the proper height adjustment of your GDS® Locking Vehicle Dock, identify the Make and Model of your device in this list, confirm the Part Number of your Vehicle Dock, and configure the “Setting #” to be the lowest number that is fully visible behind your dock.

DEVICE MAKE	DEVICE MODE	PART NUMBER	SETTING #	SETTING # WITH GDS® HANDSTAND™ & RISERS	NOTES
Apple	iPad (5 <sup>th</sup> Gen)	RAM-GDS-DOCKL-V2-AP8U	8	6	
	iPad (6 <sup>th</sup> Gen)	RAM-GDS-DOCKL-V2-AP8U	8	6	
	iPad (7 <sup>th</sup> Gen)	RAM-GDS-DOCKL-V9-OMT1U	22	23	
	iPad (8 <sup>th</sup> Gen)	RAM-GDS-DOCKL-V9-OMT1U	22	23	
	iPad Air 3	RAM-GDS-DOCKL-V2-AP16U	8	7	
	iPad mini 2	RAM-GDS-DOCKL-V2-AP2U	7	6	
	iPad mini 3	RAM-GDS-DOCKL-V2-AP2U	7	6	
	iPad mini 4	RAM-GDS-DOCKL-V2-AP27U	7	6	
	iPad mini 5	RAM-GDS-DOCKL-V2-AP27U	7	6	
	iPad Pro 10.5	RAM-GDS-DOCKL-V2-AP16U	8	7	
	iPad Pro 11"	RAM-GDS-DOCKL-V2-AP23U	5	5	Cut both foam pads for proper top cup fitment
	iPad Pro 12.9 (3 <sup>rd</sup> Gen)	RAM-GDS-DOCKL-V2-AP24U	5	4	
	iPad Pro 9.7	RAM-GDS-DOCKL-V2-AP8U	8	7	
LG	G Pad F 8.0	RAM-GDS-DOCKL-V2-LG2U	5	4	Cut foam pad for even placement on narrow side.
Samsung	Galaxy Tab 4 10.1	RAM-GDS-DOCKL-V2-SAM13U	6	5	
	Galaxy Tab 4 7.0	RAM-GDS-DOCKL-V2-SAM11U	5	4	
	Galaxy Tab 4 8.0	RAM-GDS-DOCKL-V2-SAM12-AUD1U	7	6	
	Galaxy Tab 4 8.0	RAM-GDS-DOCKL-V2-SAM12U	7	6	
	Galaxy Tab A7 Lite 8.7	RAM-GDS-DOCKL-V9-OMT1U	7	6	
	Galaxy Tab A 10.1	RAM-GDS-DOCKL-V2-SAM23U	9	7	
	Galaxy Tab A 10.1 (2019)	RAM-GDS-DOCKL-V2-SAM49U	8	7	Cut both foam pads for proper top cup fitment
	Galaxy Tab A 8.0	RAM-GDS-DOCKL-V2-SAM16U	8	6	
	Galaxy Tab A 8.0 (2017)	RAM-GDS-DOCKL-V2-SAM35-AUD1U	8	7	
	Galaxy Tab A 8.0 (2017)	RAM-GDS-DOCKL-V2-SAM35U	8	7	
	Galaxy Tab A 8.0 (2018)	RAM-GDS-DOCKL-V2-SAM40U	0	0	
	Galaxy Tab A 8.4	RAM-GDS-DOCKL-V9-SAM67U	6	5	
	Galaxy Tab A 8.4	RAM-GDS-DOCKL-V9-SAM67CU	6	5	
	Galaxy Tab A 9.7	RAM-GDS-DOCKL-V2-SAM15U	8	6	
	Galaxy Tab Active 8.0	RAM-GDS-DOCKL-V2-SAM17U	5	4	
	Galaxy Tab Active Pro	RAM-GDS-DOCKL-V9-OMT1U	29	27	
	Galaxy Tab Active2	RAM-GDS-DOCKL-V2-SAM29CU	7	6	
	Galaxy Tab Active2	RAM-GDS-DOCKL-V2-SAM29U	7	6	
	Galaxy Tab E 8.0	RAM-GDS-DOCKL-V2-SAM21U	8	7	
	Galaxy Tab S 10.5	RAM-GDS-DOCKL-V2-SAM10U	6	5	
	Galaxy Tab S 8.4	RAM-GDS-DOCKL-V2-SAM9U	7	6	
Galaxy Tab S2 8.0	RAM-GDS-DOCKL-V2-SAM18U	5	4		
Galaxy Tab S2 9.7	RAM-GDS-DOCKL-V2-SAM19U	7	6		
Galaxy Tab S3 9.7	RAM-GDS-DOCKL-V2-SAM27U	7	6		
Galaxy Tab S4 10.5"	RAM-GDS-DOCKL-V2-SAM41U	5	4		
Galaxy Tab S5e	RAM-GDS-DOCKL-V2-SAM49U	8	7	Cut both foam pads for proper top cup fitment	