
RAM[®] SEAT-MATE[™] ASSEMBLY INSTRUCTIONS (SIDE A)



8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.

RAM® SEAT-MATE™ ASSEMBLY INSTRUCTIONS (SIDE B)


VIDEOS AND INSTRUCTIONS FOR ASSEMBLY AND USE MAY ALSO BE FOUND AT: WWW.RAMMOUNT.COM



STEP 1 Slide Rear Seat Back Tube (D) under seat back and turn tube so that bent leg is facing down.



STEP 2 Turn and position Front Vertical Tube (B) under front of seat.



STEP 3 Slide both Side Swing Tubes (C) till they stop or until they are approx. 90 degrees to the Rear Seat Back Tube.



Back Tube (D) and Front Vertical Tube (B) are snug against their respective surfaces, then tighten T-Knob (X).



STEP 4 Make certain that Rear Seat STEP 5 Using one hand to press down STEP 5 Loop the seat belt around the on Front Tube (A) pull up on Hand Lift seat belt strap lug as shown and attach Knob (L) until Seat-Mate is secure on seat.

your appropriate RAM Mount.



Your RAM Seat-Mate may come with a personal travel bag, if so we recommend removing the Rear Seat Back Tube (D) prior to fitting it into the travel bag (as shown). Typically the travel bag will hold the entire RAM Mount System including the Seat-Mate, RAM Mount and a RAM Tough Tray (not shown) along with your laptop or electronic device (also not shown).



RAM Seat-Mate may be used in a wide variety of applications including but not limited to Vehicles, Boats, Aircraft, Chairs, Buses, etc.

Never use mobile computing or communication equipment while the vehicle is in motion!



PLANES



BOATS

RAM Mounting Systems 8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.