

WIRELESS CHARGING STAND INSTRUCTIONS



more info

pkdsn.com/stand

WHAT'S IN THE BOX

requires Peak Design Case
or MagSafe Phone/Case
not included



Cable Clips
x3



USB-C to
USB-C Cable
(2m)

requires
Power Adapter
(sold separately).

USE



Attach **USB-C Cable** to the back of your **Stand** and plug into wall using your **Peak Design Power Adapter** (sold separately).

Attaching Phone

Wireless Charging Stand magnetically connects to the back of your phone. Requires **Peak Design Case** or **MagSafe Phone/Case**. Once connected, confirm phone is charging via phone screen.



Removing Phone

To remove phone, peel from the bottom up.