

## How To Assemble Your Adjustable Tablet PC Mount

Place the Adjustable Tablet PC Mount onto the 4-point adapter and slide until it snaps into the locked position. You will feel it "click."

NOTE: 7/32" and 2mm Allen wrenches are included for assembly/disassembly. Keep these in a safe place.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)



The 4-point adapter may be pre-assembled to the gooseneck arm.

### May Be Pre-Assembled:



**IMPORTANT:** If you wish to disassemble your SnakeClamp, loosen the set screw using the included 2mm Allen Wrench **PRIOR** to removing the 3/8" screw.

When reassembling your SnakeClamp, tighten the 3/8" screw so that the spring washer is slightly compressed. Then gently tighten the set screw.

SnakeClamp Products LLC

[www.SnakeClamp.com](http://www.SnakeClamp.com) [support@snakeclamp.com](mailto:support@snakeclamp.com)

The logo for SnakeClamp, featuring the word "snakeclamp" in a bold, lowercase, sans-serif font. The "s" is red, and the "nakeclamp" is black. A red graphic element resembling a stylized snake or a clamp is positioned above the "e" and "a".