

130005

3 PCS DINING SET

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



www.coastercompany.com

REVISION 0 : 06/19/2011 REVISION 1 : 09/13/2011 REVISION 2 : 05/13/2016

PAGE 1 OF 4

ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- **2.** Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishment.

S.R./	,
X	

B

F



PARTS IDENTIFICATION:

ASSEMBLY TIME 60 MINUTES

TABLE TOP 1PC **SPANNER** 1 2 HEX NUT TABLE LEG 4PCS LOCK WASHER 3 **RIGHT LEG** 2PCS \mathbf{C} 4 FRAME WRENCH LEFT LEG 2PCS **D1** FRAME BOLT 6 FRONT & BACK 4PCS RAIL 7 **TOP & BOTTOM** 4PCS 8 <(IIIIIIII)> BACK SLAT DOWEL 9 2PCS MIDDLE BACK SLAT CUSHION SEAT Η 2PCS

FLAT WASHER

HARDWARE IDENTIFICATION:

1PC 16PCS

BARREL NUT 16PCS PAN HEAD SCREW 8PCS

NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT **PROVIDE THIS ITEM.**

www.coastercompany.com

1PC

8PCS


8PCS

8PCS

8PCS

ITEM: 130005


ASSEMBLY INSTRUCTIONS



PAGE 3 OF 4

ITEM: 130005

ASSEMBLY INSTRUCTIONS



COASTER. FINE FURNITURE www.coastercompany.com