

**COASTER**  
Fine Furniture®

**650153**

**SWIVEL ROCKER**

---

**ASSEMBLY INSTRUCTION**

**COASTER FINE FURNITURE**



**[WWW.COASTERCOMPANY.COM](http://WWW.COASTERCOMPANY.COM)**

---

# Assembly Instruction

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**▲ Warning!**

1. Do not attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

## PARTS IDENTIFICATION

A. LEFT BACK EAR




1PC

B. RIGHT BACK EAR




1PC

C. BACK REST




1PC

D. BASE




1PC

STEP 1.



STEP 2.



STEP 3.

