

ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE



www.coastercompany.com

Assembly Instruction

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.




Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for establishment commercial

PARTS IDENTIFICATION


ASSEMBLY TIME PER UNIT:10MINUTES

(A) TOP POST




1 PC

(B) MIDDLE POST




1 PC

(C) BOTTOM POST



1 PC

(D) HOOK



6 PCS

(E) WOODEN KNOB WITH BOLT




1 PC

(F) LEG



3 PCS

STEP 1



FINISH

