

**Step 1. Choose your 2-Wire door station**

Video Intercom only  
Surface mount



With keypad access  
Surface mount



With proximity reader  
Surface mount



With keypad access  
Flush mount



- Up to 4 door stations per installation
- You can mix and match any type you want in one installation

**Step 2. Add your 2-Wire indoor monitors**




- Up to 4 indoor monitors per installation
- Audio only handsets available if required

**Step 3. Add optional IP Module**



- Enables you to answer, see and release the door from anywhere in the world

**Step 4. Add optional electric strike**



- Provides electronic door release
- Typically require 1 no. per door station

**Step 5. Add optional push to exit button**



- If your door is not free handle release you will require a push to exit button