

## PRODUCT DATA

# DISH PLUS II



## **LOW TEMP HEAVY DUTY MACHINE DISH WASHING DETERGENT**

**A premium product formulated for use in low temperature dish washing machines and glass washers that use automatic feed systems.**

**DISH PLUS II**, is a unique blend of wetting agents and potassium based ingredients. It prevents the formation of foam and thereby helps to maximise and maintain wash pressure throughout the wash cycle. .

**Directions:** For better cleaning always scrape off excess food soil and other particles, before racking dishes. This will help prevent their entry into the wash tank which otherwise would cause foaming and prevent good cleaning. Rinse with moderately warm or hot water.

**For low temperature dish washers:**

Meter **DISH PLUS II** to maintain a pH of 14 in the wash water. Generally a dilution of 60 to 120 ml. (2 to 4 ounces) per 4 litres of wash water. Temperature should be maintained between 50 °C to 60 °C (120 to 140 deg F). Follow with a chlorine sanitizing rinse ( 50 ppm available chlorine is required in the rinse water for adequate sanitizing). Check with your local health authorities for mandatory requirements.

**Refer to the Material Safety Data Sheet for safety information.  
FOR INDUSTRIAL and INSTITUTIONAL USE ONLY.**