

# PRO 624CFL PRO 634CFL

#### Operating Instructions

Thank you very much for choosing SLIK PRO series Tripod.

The SLIK Corporation has designed your tripod to be a sturdy, rugged, dependable product that will provide you with many years of satisfactory use.

Please take a few moments to read this operating instruction carefully before use so that you can take full advantage of your Tripod's many fine features.

Retain this operating instruction in case you might want to refer back to it.

#### **⚠** Caution

This caution icon refers to information pertaining to important safety procedures in preventing injuries, or damages which may occur as a result of mishandling this product.

# 

Pan head attachment screw

 Position leg angle adjustment locks

Soft grip

Leg tip

This prohibited icon refers to information pertaining to prohibited contents. Please refer to instructions closely to avoid accidents.

M730-1

Main body

Components

Center column stopper

Center column

Upper part of

center column

Lower part of

center column

Center column base stopper

Leg lock lever

PRO 634CFL

<u>^</u>↑Caution

locking nut



PRO 624CFL

#### Pan head mounting post

#### ○ Prohibition



Do not attach a camera directly to the pan head attachment screw. This may damage both your camera and tripod.

# Equipment that can be loaded on this tripod

### O Prohibition

Specification

Max. operating height

Max. center column ext.

Max. operating height

Max. center column ext.

384 mm (15.2 in)

1,105 mm (43.4 in)

205 mm

(8 in)

(2.3 lbs)

490 mm

(19.3 in)

1,576 mm

(62 in)

295 mm

(2.6 lbs)

(11.6 in)

1,160 a

1,010 g

PRO 624CFL Folded length

Weight

Weight

PRO 634CFL Folded length

This product has been designed to handle equipment weighing under 3 kgs (6.6 lbs).

Do not overload.

Some equipments weighing under 3 kgs (6.6 lbs), such as long lenses, may not balance well due to its weight distribution. In such case, please use a larger tripod.

#### Carrying the tripod

## ○ Prohibition



Carrying a tripod with a camera left on can result in unexpected accidents. We therefore, recommend you to remove your camera while carrying the tripod.

# In case of the shock given to tripod by force

Soft grip is consumables. Replace when it is worn out.


\*Color of the soft grip can be stained. Keep out from objects.

**.**↑ Caution

When the shock has been given to the tripods &/or legs such as falling down please check well whether there are cracks, flaws, etc. on the pipes, or not. When you find any cracks, flaws, etc. on the pipes, please stop to use it and ask to repair. It may be wounded when some of fibers came out from the pipes. In that case, please do not touch it.

## Clamp head

#### Prohibition



Do not use an optional Clamp head for a carbon fiber tripod. The pipe may be damaged.


# Setting up

#### ⚠ Caution



To prevent accidental equipment fall or tripod tipping over, making sure all levers, knobs and handles on the tripod are securely tightened. And all of the three legs are opened all the way.

# Head setting



Set the new head or accessory on the pan head attachment screw. And turn the head clockwise until it comes to stop. Tighten the panning lock knob and

Tighten the panning lock knob and turn clockwise slightly.