


# SLIK®


## パンハンドル取り付け方 Install the Handles

C820-4


PRO 700DX  
PRO 700DX-AMT



ABLE 300DX, PRO 500DX  
SH-705E (PRO 330DX  
PRO 330DX-B  
PRO 340DX)  
SH-705S (ABLE 400DX-LE)



SH-706 (カーボンマスターシリーズ)  
SH-705 (PRO 500DX-AMT  
PRO 200DX II  
PRO 250DX II)



SH-704E  
(SPRINT PRO 3WAY)

