

### Inverting the center column




Always remove the pan head first before replacing the center column.




Remove the center column base stopper from the bottom of the center column.



Loosen the center column stopper and the locking collar, and then pull out the center column.




Insert the center column from lower side of main body, and tighten the locking collar and the center column stopper.




Always be sure to return the center column base stopper back on the center column.

This prevents the center column pulled out accidentally.




By inverting the center column, it is possible to do copy and close up work.

### How to change the pan head fixing screw



The pan head fixing screw is reversible for either large thread (U3/8) or amall thread (U1/4").

- Move the plate cover down.
- 2. Loosen the small screw in about three turnings with an allen wrench (2.5mm width)
- Loosen the plate without removing the small screw.



- again after reversing top and bottom.
- tighten the small screw by an allen wrench.


### Care of the tripod

- . DO NOT apply any grease or oil to this product.
- . Clean with a mild detergent and a soft cloth only.
- . DO NOT use close to flame. Avoid extreme heat.



Slik Corporation reserves the right to make changes in design and/or improvements on the products without any obligation and ad vanced notice.

### SLIK CORPORATION



## 4. Loosen the pan head fixing screw and pull it out. Then, screw it in

- 5. Adjust the height of screw in approx. 8mm above the plate, and then
- 6. Put the plate cover back.

J918-3

## SLIK® PRO 780DX, PRO 580DX Tripod

### Operating Instructions

Thank you very much for choosing SLIK PRO780DX, PRO580DX Tripod. The SLIK Corporation has designed your tripod to be a sturdy, rugged, dependable product that will provide you with many years of satisfac-tory use.

Please take a few moments to read this instruction sheet carefully before use so that you can take full advantage of your Tripod's many

Retain this instruction sheet in case you might want to refer back to it.

This caution icon refers to information pertaining to important safety procedures in preventing injuries, or damages which may occur as a result of mishandling this product.

### ○ Prohibition

This prohibited icon refers to information pertaining to prohibited con-tents. Please refer to instructions closely to avoid accidents.

### Specification


PRO 780DX Folded length 815mm (32.1in) 1,930mm Max. operating height (75.9in) 380mm Max. center column ext. (14.9 in) 3,670g Weight (8.1lbs) PRO 580DX Folded length 730 mm (28.8 in)

Max. operating height 1,679 mm (66 in)

Max. center column ext. 260 mm (10.2 in)

Weight

2,780g (6.2lbs)



## Pan head mounting post



Do not attach a camera directly to the attachment screw of the center column.

This may damage both your camera and tripod.

# Setting up ♠ Caution ○ Prohibition

To prevent accidental equipment fall or tripod tipping over making sure all levers, knobs and handles on the tripod are securely tightened, and all three legs are opened all the way.

Carrying the tripod



Carrying a tripod with a camera left on can result in unexpected accidents. We, therefore recommend you to remove your camera while you are carrying the tripod.

853 Kayama, Hidaka City, Saitama 350-1231, Japan Phone 81-42-989-2141, Fax. 81-42-985-0210 @2015