

SBH-120 N


このたびは、スリック製品をお買い求めいただきまことにありがとうございます。ご使用前にこの説明書をよくお読みいただき正しく、十分に性能を活かしてお使いください。お読みになったあとは必ず保管し、わからないときには再読してください。

⚠ 注意 このマークは取扱いを誤った場合、人が傷害を負ったり物的損害の発生が想定される内容です。

🚫 禁止 このマークは禁止(してはいけないこと)内容です。説明にしたい事故のないようお使いください。

English instruction in reverse side

各部名称




仕様

全高	75 mm
質量	130 g
カメラネジ	U1/4"
雲台取り付けネジ (ダブルネジアダプター付属)	U1/4" (U3/8")


持ち運びの時

🚫 禁止




カメラは一脚及び三脚から外して持ち運んでください。カメラの落下、使用者や周囲の人へのケガ、物損等を起こす可能性があります。

三脚への取り付け方




ボールロックレバーをしっかり締めてから三脚等に取り付けます。

カメラの取り付け方




カメラをささえながら、ボールロックレバーをゆるめ、カメラ台を回転させて固定します。

雲台の使い方




カメラをささえながらボールロックレバーをゆるめると、カメラ台を自由に動かすことができます。アングルを決めてボールロックレバーをしっかり締めてください。

カメラをささえながらボールロックレバーをゆるめると、カメラ台を自由に動かすことができます。アングルを決めてボールロックレバーをしっかり締めてください。




雲台の使い方

カメラをささえながら、ボールロックレバーをゆるめ、カメラ台を回転させて固定します。




カメラの取り付け方

ボールロックレバーをしっかり締めてから三脚等に取り付けます。



三脚への取り付け方

カメラは一脚及び三脚から外して持ち運んでください。カメラの落下、使用者や周囲の人へのケガ、物損等を起こす可能性があります。




🚫 禁止

持ち運びの時

L538

全高	75 mm
質量	130 g
カメラネジ	U1/4"
雲台取り付けネジ (ダブルネジアダプター付属)	U1/4" (U3/8")

仕様



各部名称

English instruction in reverse side

このたびは、スリック製品をお買い求めいただきまことにありがとうございます。ご使用前にこの説明書をよくお読みいただき正しく、十分に性能を活かしてお使いください。お読みになったあとは必ず保管し、わからないときには再読してください。

⚠ 注意 このマークは取扱いを誤った場合、人が傷害を負ったり物的損害の発生が想定される内容です。

🚫 禁止 このマークは禁止(してはいけないこと)内容です。説明にしたい事故のないようお使いください。

SLIK SBH-120 N


SBH-120

Thank you very much for choosing SLIK product. SLIK Corporation has designed to be a sturdy, rugged, dependable product that will provide you with many years of satisfactory use. Please take a few moments to read this operating instruction carefully before use so that you can take full advantage of many fine features. Retain this operating instruction in case you might want to refer back to it.

⚠ Caution This caution icon refers to information pertaining to important safety procedures in preventing injuries, or damages which may occur as a result of mishandling this product.

🚫 Prohibition This prohibited icon refers to information pertaining to prohibited contents. Please refer to instructions closely to avoid accidents.

Components




Specification

Height	75 mm
Weight	130 g
Tripod mounting screw	U1/4"
Camera mounting screw (Removing double screw adaptor)	U1/4" (U3/8")


Carrying the tripod

🚫 Prohibition




Carrying a tripod with a camera left on can result in unexpected accidents. We therefore, recommend you to remove your camera while carrying the tripod.

Attaching to the tripod




Fasten the ball locking lever and screw into a tripod mounting screw.

Attaching a camera




Loosen the ball locking lever. Having a camera, rotate the camera platform and fix it firmly.

Operation




A camera can be moved freely while the ball locking lever is loosened. Tighten the ball locking lever when a camera angle is determined.

A camera can be moved freely while the ball locking lever is loosened. Tighten the ball locking lever when a camera angle is determined.




Operation

Loosen the ball locking lever. Having a camera, rotate the camera platform and fix it firmly.




Attaching a camera

Fasten the ball locking lever and screw into a tripod mounting screw.



Attaching to the tripod

Carrying a tripod with a camera left on can result in unexpected accidents. We therefore, recommend you to remove your camera while carrying the tripod.




🚫 Prohibition

Carrying the tripod

Height	75 mm
Weight	130 g
Tripod mounting screw	U1/4"
Camera mounting screw (Removing double screw adaptor)	U1/4" (U3/8")

Specification



Components

Thank you very much for choosing SLIK product. SLIK Corporation has designed to be a sturdy, rugged, dependable product that will provide you with many years of satisfactory use. Please take a few moments that you can take full advantage of many fine features. Retain this operating instruction in case you might want to refer back to it.

⚠ Caution This caution icon refers to information pertaining to important safety procedures in preventing injuries, or damages which may occur as a result of mishandling this product.

🚫 Prohibition This prohibited icon refers to information pertaining to prohibited contents. Please refer to instructions closely to avoid accidents.

Operating Instructions