

**Volonic<sup>®</sup>**

**VALET 3**

**USER MANUAL**

# VALET 3 - OVERVIEW

## Product overview

1. Charging surface (gray surface in image)
2. USB-C input port
3. LED indicators
4. Rubber legs

## Specification:


- Dimensions - 23 x 13.5 x 1.45cm (9.05 x 5.32 x .57in)
- Weight - 692grams (1.5lbs)

## In The Box:

- Volonic Valet 3
- Volonic 36W USB-C PD wall charger
- Volonic 6FT (1.8m) USB-C to USB-C cable
- Authenticity / registration card

## LED characteristics:


- LED on solid - Device detected and charging
- LED blinking - Unidentified object detected on charging surface, remove device and try again
- All 3 LED's blinking - Contact our support team at [concierge@volonic.com](mailto:concierge@volonic.com) or 1-833-VOLO-100



#2 - USB-C Port


BACK

#1 - Charging surface



Volonic

FRONT



#4 - Rubber legs

#3 - LED Indicators

# VALET 3 - USER MANUAL

## How to use:


1. Remove giftbox from sleeve
2. Open giftbox to unveil your beautiful Volonic Valet 3
3. Under your Valet 3 is an envelope with your Authenticity card and unique serial number
  1. To register your device, scan the QR code on the back of your authenticity card tray
  2. Enter last 6 digits of serial number
4. Remove authenticity card tray to access provided wall charger and cable
5. Plug USB-C wall charger into your power outlet
6. Attached USB-C cable into wall charger, make sure a "click" sound is heard
7. Plug other end of the USB-C cable into your Valet 3, make sure a "click" is heard
8. All 3 LED's on your Valet 3 should cycle on, then off
9. Now enjoy the freedom of being able to wirelessly charge your device anywhere on the top surface

For frequently asked questions, please visit <https://volonic.com/pages/faqs>


If additional assistance is needed, please reach out to our support team at [concierge@volonic.com](mailto:concierge@volonic.com) or

1-833-VOLO-100


Scan →



"Click"



"Click"



# VALET 3 - PRODUCT CARE

## Housing

- To clean use a soft cloth (cotton or microfiber) and gently wipe clean
- Spray glass cleaner onto soft cloth (cotton or microfiber) and gently wipe
  - Do NOT spray directly on to product
  - Do NOT use ammonia or bleach-based cleaners

## Top plate

- Alcantara®
  - It is sufficient to dust Alcantara® using a soft brush, a dry cloth, a lint roller, or a vacuum cleaner.
  - After having dusted Alcantara®, run a slightly moistened white cotton cloth over it. Avoid the use of printed absorbent cloths/papers as they can release ink onto the material.
  - For stains; act immediately (within 30 minutes) and begin treating the stain from the outside edge into the center in order to avoid the stain spreading
    - Never apply a cleaning product directly onto Alcantara®
    - For liquids, use non-printed absorbent paper or a sponge
    - Avoid rubbing to prevent the stain from spreading or going deep into the material
    - Use a white cloth or a well wrung sponge for the removal of the stains; if you use a sponge, rinse it in clean water and wring it well between each wipe.
- Leather
  - To clean use a lightly damp soft cloth (cotton or microfiber) and wipe clean
  - For a deeper clean
    - mix a solution of warm water and dish soap
    - Dip a portion of a soft cloth into the solution, wring cloth to remove excess water, and wipe surface.
    - Use second clean damp cloth with only warm water to wipe soap off
    - Dry surface by using dry towel and dabbing
  - Do NOT use ammonia or bleach-based cleaners

## Warning

- Keep liquids away from product and ports
- Do not disassemble your Valet 3

If you have any questions or concerns contact our support team at [conciierge@volonic.com](mailto:conciierge@volonic.com) or 1-833-VOLO