


MIYOTA 8205

AUTOMATIC MECHANICAL MOVEMENT

"AUTOMATIC SELF-WINDING - 21 JEWELS" No batteries required with a 40-hour power reserve



*Date & Day of the week position may be located at different position depends on models.

B) SETTING THE TIME


- 1. Pull the crown out to the 2nd position.
- 2. Turn the crown to set hour and minute hands.
- 3. When the crown is pushed back to the normal position, second hand begins to run.

C) SETTING THE DATE

- Pull the crown out to the 1st position.
 Turn the crown counter-clockwise to set the date.
- * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
- 3. After the date has been set, push the crown back to the normal position.

D) SETTING THE DATE OF THE WEEK

- 1. Pull the crown out to the 1st position.
- 2. Turn the crown clockwise to set the day of the week.
- * If the date is set between the hours of around 9:00 PM and 1:00 AM, the day of the week may not change the following day.
- 3. After the day of the week has been set, push the crown back to the normal position.



Instruction Manual MIYOTA 8205 AUTOMATIC MECHANICAL MOVEMENT

Water Resistance

Indications			Use in water				
Watch Dial mts / ft	Back of the watch case		5			5.	
30 mts / 100 ft	W/R 3 atm	YES	YES	YES	NO	NO	NO
50 mts / 160 ft	W/R 5 atm	YES	YES	YES	YES	NO	NO
100 mts / 330 ft	W/R 10 atm	YES	YES	YES	YES	YES	NO
200 mts / 660 ft	W/R 20 atm	YES	YES	YES	YES	YES	YES