




MULCO

Instructions Manual
English
Miyota GL30
Analog








SETTING THE TIME

- Completely remove the crown (position II), the second hand will hold (adjustment to the second)
- Set the correct time by turning the crown
- Press the threaded crown (position I), the clock will continue to run

BATTERY INDICATION

The state of the battery is controlled. If the battery is almost worn, this will be signaled by 4 second seconds of the second hand.


WATER RESISTANCE

Indications		Use in water				
Watch Dial	Back of the watch case	 Light exposure (light spray, perspiration, light rain)	 Moderate exposure (swimming, washing dishes, etc)	 Skin diving, water sports (no oxygen cylinder)	 Scuba diving with oxygen cylinder	 Pulling out the crown when the watch is wet
3 atm	W/R 3 atm	OK	NO	NO	NO	NO
5 atm	W/R 5 atm	OK	OK	NO	NO	NO
10 atm	W/R 10 atm	OK	OK	OK	NO	NO



MULCO

Manual de instrucciones
Español
Miyota GL30
Analógica




AJUSTE DE LA HORA

- Extraer completamente la corona (posición II), el segundero se detendrá (ajuste al segundo)
- Ajustar la hora correcta girando la corona
- Presionar la corona roscada (posición I), el reloj seguirá marchando

INDICACIÓN DE FIN DE LA PILA

El estado de la pila es controlado. Si la pila está casi gastada, esto será señalizado por saltos de 4 segundos del segundero.

RESISTENCIA AL AGUA

Indicaciones		Uso en el agua				
Dial	Tapa Trasera	 Exposición menor (lavarse la cara, lluvia)	 Exposición moderada (lavar, tareas de cocina, natación)	 Buceo de superficie, deportes marinos	 Buceo con escafandra usando un tanque de aire	 Halar la corona para afuera cuando el reloj está mojado
3 atm	W/R 3 atm	OK	NO	NO	NO	NO
5 atm	W/R 5 atm	OK	OK	NO	NO	NO
10 atm	W/R 10 atm	OK	OK	OK	NO	NO