PULSAR proshift™

USER MANUAL

Thank you for purchasing the Pulsar® ProShift™ Vaporizer!

In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.

Pulsar® ProShift™ Overview

- Mouthpiece
- Power Button
- Display
- Control Button +
- Control Button –
- Charging Port

Includes

- Mouthpiece Filter
- USB-C Cable
- Chamber Cleaning Brush
- Airpath Cleaning Brush
- Cleaning Wipe

Important Usage Tips

- Rapidly press power button 5 times, activation of power On/Off will be confirmed by haptic feedback.

- Press and hold power button and "-" button simultaneously for 2 seconds to change from Fahrenheit to Celsius degrees and vice versa.

- Session timer setting: hold power button for 2 seconds until selection is positioned under SET of timer, press control button +/- to adjust working time from 180 to 420 seconds.

- 248-430 °F / 120-221°C When the selected temperature is reached, device will notify you with haptic feedback.

- Display indicates temperature information, battery status, duration timer.

- Quick battery check: one hit on power button when device is off, the icon on screen will show remaining battery level.


Display Indication

Fahrenheit Display
The default display is Fahrenheit. Mark SET (page 4) to select the temperature.

TEMP 320°F SET 330°F
TIME 320 s SET 405 S

Celsius Display
Mark SET (page 4) to select the temperature.

TEMP 200°C SET 180°C
TIME 320 s SET 405 S

Timer Display
Mark SET (page 4) to select the operating time.

TEMP 320°F SET 330°F
TIME 320 s SET 405 S

---

1   2   3   4   5

How To Load Dry Herb

① Remove mouthpiece from the device.

Loose Dry Herb

② Loosely load choice dry herb into heating chamber. Do not over-fill.

③ Attach mouthpiece back to the device.

How To Clean Heating Chamber

① Pull out the onboard stir stick.

② Remove mouthpiece from the device.

③ Remove material from chamber.

④ Use the cleaning brush to remove the remaining residue from the chamber.

Load/Remove The Mouthpiece Components

- When loading or removing mouthpiece components, make sure the mouthpiece is open.

Mouthpiece Open   **Mouthpiece Closed**

Insert

25°

- Place mouthpiece components and device at 25° angle, it will be magnetically attached to the device.

- When removing, follow above steps in reverse.

How To Maintain The Zirconia Airpath

① The zirconia mouthpiece can be removed for cleaning or replacing.

② Pulsar® ProShift™ zirconia airpath can be pulled out for cleaning or replacing.

③ The mouthpiece O-ring or screen can be removed for cleaning or replacing.

④ After maintenance, reassemble the mouthpiece.

How To Clean The Zirconia Airpath

① Remove and disassemble mouthpiece (page 9)

② Clean the **zirconia mouthpiece** and **airpath** with a cotton swab and **isopropyl alcohol.** Note: these pieces can also be soaked in alcohol.

③ Clean the rest of the mouthpiece with a mild detergent and cloth.

④ Clean the chamber with alcohol and a cotton swab, **do not put alcohol directly into the chamber.**

⑤ Once all the pieces have air dried the mouthpiece can be reassembled.

Charging Instructions

- Battery capacity **3000 mAh,** USB-C charging, **5V/2A** suggested.

- Initially charge the Pulsar® ProShift™ for **2 hours.** The battery will stop charging when the icon is full.

- When battery level is low, charge battery with included USB-C cable to compatible wall charger. Low battery level will be indicated with icon.

- Do not use Pulsar ProShift while charging.

PULSAR®
ENJOY HIGHER CULTURE™

Manufactured by Pulsar®
Asheville, NC 28806

Designed in USA • Made in China

Not intended for tobacco or illegal substances.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

🚭 21+