alula

Simplifying · Security

Doorbell Camera

Quick Start Guide

SAVE THIS MANUAL FOR FUTURE REFERENCE

Quick Setup

Power Kit Installation

Doorbell Mounting

Doorbell Setup

What's in the Box

Doorbell (x1)

Faceplate (x3)

Pick the one that best matched your home from three faceplates.

Mounting Plate (x3)

Pick the one for best surveillance angle.

Screwdriver (x1)

Plate Foam (x1)

Stabilize the mounting plate when installing it in the rough surface.

Drill Bit (x1)

Power Kit (x1)

Wire Harness (x1)

Wire Connectors (x4)

Mounting Screws (x3)

Anchors (x3)

Fuse Wire (x1)

Security Screws (x2)

Fixing Screws (x2)

Mini-Level (x1)

U-shaped Wires (x2)

Doorbell Screws (x2)

Tools You May Need

Drill

Pencil

1

Power Kit Installation

- If you have the mechanical chime in your home, start from Step 1 here.
- If you have the electronic chime in your home, please refer to its manual for detailed operations.
- If you do not have any chime, skip power kit installation and follow the Option B in page 5.

1 Shut off the electricity at the breaker that controls doorbell's circuit.

2 Insert one end of the wire harness the power kit.


3 Remove the cover from your mechanical chime.

4 Remove the existing chime wires in the terminals named TRANS and FRONT.

5 Connect the wire harness to the chime's terminals named TRANS and FRONT.

6 Insert the existing chime wire and the other end of the wire harness into the wire connector and twist it tightly. Repeat this step with the other chime wire.

REAR **TRANS** **FRONT**

Wire Connector

Chime Wire

Wire Harness

Wiring Overview

REAR TRANS FRONT

REAR TRANS FRONT
DO NOT OIL

Chime Wire

Power Kit

Chime Wire

7. Mount the power kit to the side of the chime.

8. Put back the chime cover.

Doorbell Mounting

**1** Shut off the electricity at the breaker that controls doorbell's circuit.

**2** (Optional) Paste the plate foam to the mounting plate.

i Use the plate foam when your wall is uneven.

3 Insert the mini-level into the mounting plate and mark the drill points when its bubble stays in the middle.


Mini-Level

i Remove the mini-level when drill points are marked.

**4** Drill holes according to drill points and insert anchors.

Anchor

5 Fix the mounting plate to the wall.

Mounting Screw

6 If power kit is installed, follow Option A; If not, follow Option B.

**Option A** Connect doorbell with your existing doorbell wires.

U-Shaped Wire

Fixing Screw

Option B Connect the fuse wire with your existing doorbell wire.

U-Shaped Wire

Fixing Screw

7 Fix the doorbell to the mounting plate by inserting the doorbell screws.

**8** Restore the electricity at the breaker.

Doorbell Screw

ⓘ Doorbell is powered on when its indicator flashes blue quickly. If not, make sure your electricity is off and check the wiring. If yes, proceed to doorbell setup.

Doorbell Setup

9 Add to Alula app.

- Add a camera to the Alula app
  - Log in to your account using the Alula app.
  - From the Alula app Camera screen, tap "+" on the upper-right hand corner to go to the scan QR code interface.


- Scan the QR Code on the bottom of the camera.
- Enter the verification code located on the bottom of the camera.
- Follow the app wizard to finish Wi-Fi configuration.

ⓘ If you want to change your camera's Wi-Fi, press and hold the reset button for 10s and repeat this part.

10 Put the faceplate back and insert two security screws into the bottom of the doorbell to secure the faceplate.

Security Screw

Appendix

Basics

Mounting Holes

micro SD
Card Slot

Reset Button

Hold for 5s to reset and
enter to AP mode.

Terminals

SD Card Management

If the memory card status displays as
Uninitialized, tap to initialize it.

LED Indicator

Blue Light	Flashing	Doorbell AP Mode is on.
	Steady on	Doorbell is working.
Red Light	Flashing Fast	Device Exception
	Steady on	Doorbell is powering on.