Wi-Fi Emergency call button

Instructions

Appearance Introduction

- Lanyard
- Button
- USB charging
- LED indicator light
- Charging indicator light

Preparation before connecting to the APP

Download APP

Tuya Smart

Smart Life

➢ Scan the QR code to download.
➢ Please search for "Tuya Smart (Smart Life)" in the application market to download.

The usage of the two apps is similar, just choose one of them.

Configuration network considerations

WI-FI 6: 2.4G 802.11 B/G/N20/N40/AX20

≤ 15 meters (open/undisturbed)

Warm prompt

The distance varies with the environment.
If the button is too far from the router, it will not be able to connect to the phone.

Connect to mobile app

❶ Connect your phone to Wi Fi (2.4G) and turn on Bluetooth.

---

❷ Enter the configuration network state.

Press and hold the button for 10 seconds, and the LED indicator light will slowly flash.

Warm prompt

The duration of configuring network status is 2 minutes.

---

❸ Open the app and click on "Add Device".

❹ After automatically discovering the device, click "Add".

---

❺ Enter WiFi information and password.

---

❻ Waiting for successful connection.


❼ Successfully connected, click "Done".

Alarm push notification

Short press

The LED indicator flashes quickly.

Multi-person sharing

❶ Click on the upper right corner ✎

---

❷ Click "Share Device".

- Device Information
- Device Network
- Tap-to-Run and Automation
- Device Offline Notification
- Offline Notification
- Others
- Share Device

---

❸ Click "Add Sharing".

When the device is not connected to the network, the person with whom you have shared the device may not be able to control the device.

SOS button has not been shared

---

❹ Choose a sharing method.

Share with the Account 添加账号

Share with Others   1 person(s)

Messages   Copy   More

Installation

Installation method

Double-sided tape can stick SOS Button to the bathroom / toilet / kitchen, etc.

Lanyard design that can be hung around the neck.

Double sided adhesive installation

Tear off one side of the double-side adhesive tape.

Paste on the back of the button.

Q&A

Q: **After configuring the network, trigger the button. The LED indicator light is constantly flashing.**

A: (1) Because the button has exceeded the Wi-Fi range, the alarm was not successfully reported. Need to approach Wi-Fi and stop flashing after successful reporting.
(2) Automatically stop after waiting for 2 minutes.

Q: **Unable to connect to mobile app?**

A: The button is too far away from the router. Please connect within 1-3 meters of the router.

Technical specifications

Standby current: 0.1μA
Average current: 12mA
Internal battery: polymer battery 3.7V/400mAh
Charging duration: ≤ 1 hour
Wi-Fi 6: 2.4G 802.11 B/G/N20/N40/AX20

尺寸：500x60mm