# How do I connect my Roborock device to Wi-Fi on an iOS device?

1. **Download the Mi Home from the App Store.**

2. **Register for a Mi Home account using your phone number (Skip this step if you already have a Mi Home**

account).

2. Add Roborock Device

Notes:

a. *Make sure your phone is already connected to Wi-Fi;*

b. *Open the top of your cleaner to see the Wi-Fi indicator light during the connection process.*

    3.1 Sign in to you Mi Home account.

    3.2 Tap the "+" icon to add a device.

   3.3 Select Roborock Vacuum from the "Home appliance" category.

    3.4 Tick "Blue Light Blinking".

    3.5 Select your home Wi-Fi and input your Wi-Fi password.

Cancel	Add Roborock Vacuum		Cancel	Select Wi-Fi network

yourhomewifi

yourwifipassword

Hide password

⚠ 5G Wi-Fi not supported

Switch Wi-Fi networks

Next

Turn on the device and open the upper cover,
make sure it's available to connect

Light status error

✓ Blue light blinking

Next

3.6 Tap "Go to Wi-Fi Settings".

3.7 Select Wi-Fi network named roborock-vacuum-xxxx to connect.

Cancel	Select Wi-Fi		‹ Settings	WLAN

WLAN ⬤

✓ roborock-vacuum-t6v2_miap64... 🛜 ⓘ
Unsecured Network

•••• 中国联通 📶 15:46 ⚡ 📱 98% 🔋
‹ 设置 **Wi-Fi**

✓ roborock-vacuum 🛜 ⓘ

Xiaomi_7CE8 🛜 ⓘ

选取网络...

!Xiaomi_7CE8_5G 🔒🛜 ⓘ

(netcore_xiaotong 🔒🛜 ⓘ

CHOOSE A NETWORK...

EZVIZ_C28988527 🔒 🛜 ⓘ

HiWiFi_2C7274 🔒 🛜 ⓘ

private 🔒 🛜 ⓘ

Roborock 🔒 🛜 ⓘ

RRvpn1 🔒 🛜 ⓘ

RRvpn1_5G 🔒 🛜 ⓘ

Connect your phone to "roborock-vacuum_xxx"
and return to Mi Home app

Test 🔒 🛜 ⓘ

Test_5G 🔒 🛜 ⓘ

TimeLink5G 🔒 🛜 ⓘ

⚠ Current Wi-Fi: Roborock

TP-LINK_8E49 🔒 🛜 ⓘ

Go to Wi-Fi settings

Other...

3.8 Go back to the Mi Home app and the connection interface will appear. Wait until it reaches 100%.

3.9 Select the location of device and give it a name.

Note:

The Wi-Fi indicator on the top of your vacuum will go from flashing to solid if it has connected successfully.

Location of device Default room >	Share device with
Device name Roborock Vacuum >	

OK

2/3

Let's get started

3/3

3. Access device to operate.

3.1 Tap the device in the Mi Home homepage and wait until initializing reaches 100%.

3.2 Select your current region and you are ready to control your device from the app.

🏠 Andy Wan's home

My devices Home appliances Bedroom

Roborock Vacuum

Roborock Vacuum

Initializing device 22%

Cancel

Roborock Vacuum
Getting info...

Please select your country or region
Your current local server: Singapore

EU(EU)

Singapore(Singapore)

Taiwan(臺灣地區)

Hong Kong(香港地區)

Korea(대한민국)

USA(USA)

Canada(Canada)

Russia(Россия)

QUIT OK

Roborock Vacuum
Clean

Edit map

1 m²	100 %	0 ´
Cleaning area	Remaining battery	Cleaning time

GO Dock Pause Zoned cleanup