NEO STREAM

Quick Start Guide

Scan QR code for Set-Up Guide videos





1 Power

*A power supply unit must be able to deliver minimum rated repetitive current.

2 Input



*Only one ethernet connection shall be used at any given time.



3 Output

Amplifiers DACs Active Speakers



Before using NEO Stream, review the NEO Stream User Manual at https://ifi-audio.com/product-guides/

Wi-Fi Set-Up

1 Connect Wi-Fi antenna and power supply
DAC, Amplifier or Active Speakers via S/PDIF, RCA or USB



A power supply unit must be able to deliver minimum rated repetitive current.

2 Power on

3 Select Hotspot and set to ON



4 In your device's Wi-Fi setting, connect to 'iFi-Streamer'

5 On your phone browser enter "192.168.211.1" in to URL box (not search box)

6 Connect the iFi-Streamer to your local Wi-Fi network

Enter network password and press Connect

IP address will show once connected

7 Network status LED

Connection speed
- Fast (Internet)
- Slow (Internet)
- Fast (Local network)
- Slow (Local network)
- No connection

8 Connect your phone back to local Wi-Fi network (If not already connected)

9 Go to Music Streaming section

Ethernet Set-Up

1 Connect LAN and power supply
DAC, Amplifier or Active Speakers via S/PDIF, RCA or USB



A power supply unit must be able to deliver minimum rated repetitive current.

2 Power on

3 Ready to connect

Connection speed
- Fast (Internet)
- Slow (Internet)
- Fast (Local network)
- Slow (Local network)
- No connection

4 IP address will show once connected

Music Streaming

TIDAL

Open Tidal app

Spotify qobuz YouTube Music

Other compatible apps are available