IColor 800W
**Digital Color + White Transfer Printer**

Quick Start Guide

For detailed instructions, please refer to the Uninet IColor 800W Printer User Manual and the Uninet IColor ProRIP User Manual

## 1. Remove the packing materials and check the components

Uninet IColor ProRIP dongle

Uninet IColor 800W

10 cm (4.0")
10 cm (4.0")
75 cm (29.6")
68.5 cm (27.0")
58.7 cm (23.2")
55 cm (21.7")
58.7 cm (23.2")

## 2. Remove orange tape

· From all sides

3. Remove orange security tape and lock from inside printer

4. Connect the printer power cord and turn on.

① ②

5. The Uninet IColor 800W Digital Color + White Transfer Media Printer has one configuration

| Printer Display Reads	Replace with
Cyan low/out/empty	Cyan
Magenta low/out/empty	Magenta
Yellow low/out/empty	White
Black low/out/empty	Yellow

W M C Y

⚠ **WARNING** Replace with UniNet OEM supplies only! Incompatible supplies will damage the printer.

6. Install the Uninet IColor ProRIP (stored on the provided dongle)

Please disable/uninstall any Anti Virus software before installation of the UniNet ProRIP

· Choose your language and follow the install steps

SetUp
Application Type. Choose either 32-bit or 64-bit application type. To Continue, select Next.

IColor ProRIP Setup
InstallShield Wizard for IColor ProRIP
The InstallShield Wizard will install IColor ProRIP on your computer. To Continue, select Next.

IColor ProRIP Setup
License Agreement
Please read the following license agreement carefully. If you agree, Accept and select Next.

IColor ProRIP Setup
Installation Choices
Choose 'Full install of iColor ProRIP' and select Next.

IColor ProRIP setup
Choose Destination Location. Select folder where setup will install files. To Continue, select Next.

IColor ProRIP setup
Select Program Folder. Please select a program folder. Setup will add program icons to the Program Folder listed below. You may type a new folder name, or select one from the existing folders list. Select Next to continue.

IColor ProRIP Setup
Agree to license terms and select Install.

7. Uninet IColor ProRIP software

First time Setup

- Ensure the ProRIP dongle is inserted and you are connected to the internet (required)

- Launch the software

- Set unit of measure and decimal places, then select OK.

First Time Setup

You are running iColor ProRIP for the first time. Please review initial settings and modify to suit your preferences.

Where applicable, all numeric values will be displayed using the selected units and number of decimal places set below.

Set display units: inches

Set number of decimal places: 2

To change these settings, and for advanced options, click on 'Tools->Options...' after the application begins.

OK

9. ProRIP opens, the Queue Wizard will begin the installation of the support files for your IColor 800 printer

- Select next

**Create Queue Wizard**

Introduction

Welcome to the production queue setup wizard.

This wizard will set up your local production queue. A production queue manages your print and cut jobs for your configured printers and cutters.

To continue, click 'Next', or click 'Cancel' to quit.

Back | Next | Cancel

- Select Install Printer

Create Queue Wizard

Printer Defaults

Assign a default printer for this production queue.

Select the default printer, print mode, and output port for this queue:

Printer:

Install Printer

Port: FILE

Print mode:

Back | Next | Cancel

10. Select the IColor 800 printer from the support menu and select 'OK'

Install Printer

Select a printer from the list you want iColor ProRIP v2 Dealer to support

Search: | Clear

Select none | Items selected: 1

UniNet iColor 500 v2
UniNet iColor 540 v2
UniNet iColor 550 v2
UniNet iColor 600 v2
UniNet iColor 800W

OK | Cancel

11. Device package search

- Select 'Search' for new printer package

- Select 'Next' to continue the installation

Create Queue Wizard

Add Printer

Device Package Search

○ Search for new printer package(s) from DVD or Cloud server.
  ☑ Search Cloud server for printer package(s).
    Internet access required for this search to take place
  ☐ Search DVD.
    Please insert Printer DVD supplied with Rip Software

○ Don't search automatically, I will choose the search location
  Select this option if you would like to select a printer package from a specific location. This printer package may not be the most recent version available.

Browse...

Back | Next | Cancel

Add Printer

Copying Device Packages

Overall copy progress
✓ Installation Complete

Download progress
✓ UNI800W.1.7.RQ.pkg64 From updater
  Downloaded: 6.77 MB copied in 2 seconds
  Transfer rate: 9.17 MB/Sec

Extraction progress
✓ Extraction Complete

Device package update is complete. Click 'Next' to continue.

Next

12. Select 'Finish' to complete the installation

- Please continue for software configuration

Add Printer

Configuration Summary

You have completed the Install Device Wizard.

UniNet iColor 800W
Driver package [Version 1.7]: Installed successfully

Finish

13. Uninet IColor ProRIP printer queue setup

- Open the IColor ProRIP

- Select Queue/Manage Queues

- Select the proper port from the 'Port' drop down menu.

  – If connected via network (recommended), choose TCP/IP.

  – If connected by USB, choose the printer as identified in the drop down

    * All other ports will update automatically, it is only necessary to do this for one queue

  – Select 'Close'

14. Select the proper Print Queue for your project

A. Select your 'Print Que' and 'Print Mode'

  – The 'Print Modes' have preset values for white coverage, choke, paper size, paper tray and mirror settings

    These can be modified as needed

Print Queue

Print Mode Selection

15. Import + print graphic

A. Three ways to import graphics

  – 1. Select the 'green plus' icon and navigating to the proper folder.

  – 2. Select File > Import File

  – 3. Simply dragging and dropping your file into the queue

B. Select the desired file

C. Select 'Print' icon in the menu bar.