UP-STAGING EXTRA TIER B2(01)
Assembly Instructions

COMPONENTS		LENGTH					
		1'11"	3'10"	5'9"	7'7"	9'6"	11'5"
A Corner Bracket	2"	4	4	4	4	4	4
B Mid Bracket Left hand	2"	2	3	4	5	6	7
C Mid Bracket Right hand	2"	2	3	4	5	6	7
D Corner Bracket	18"	4	4	4	4	4	4
E Mid upright Left hand	18"	-	1	2	3	4	5
F Mid upright Right hand	18"	-	1	2	3	4	5
G Cross Angles (Width of Staging)		2	3	4	5	6	7
H Long Sides	1'11"	2	-	2	-	2	-
H Long Sides	3'10"	-	2	2	4	4	6
Bolts and Nuts		16	24	32	40	48	56
Trays	22" X 17/21/24/29/34	1	2	3	4	5	6

N.B. Each staging length is made up using multiples of either 1'11" or 3'10" Long Sides I.E. 7'7" = 3'10" +3'10" or 9'6" = 3'10" + 3'10" + 1'11" etc.

1. Please check the components.

2. Decide where you wish to position the extra tier i.e. over the whole upstaging, at one end or in the middle.

3. Attach the corner and mid brackets to the outside of the top of the appropriate legs of the staging using the existing bolts and nuts.

4. Fasten the corner and mid – uprights to these brackets.

5. Fit the cross angles and long sides to the top of the uprights.

6. Position the trays.

Long Term Care of Aluminium
Prolonged exposure and contact with chemicals containing metal compounds can have a corrosive effect on aluminium.
Typical of these are modern fertilisers that can contain Potassium and Potassium Chloride or more traditional such as Cheshunt Compound and Bordeaux Mixture, both of which contain Copper. All of these, when mixed with water, create Ionic Salts which can attack the surface and cause pitting, eventually leading to small holes appearing in the aluminium.
When using any metal based chemicals it is best to line any aluminium surface with polythene or to wash down thoroughly after each application. When using an unlined bench as a capillary bed with sand or matting, apply the chemicals away from the bed and drain well before replacing.
If you're in any doubt, please check the manufacturers label as this will include a list of the contents.