AEROPEX PLAY

User Guide

한국어

日本語



8000500055(A0)

ENGLISH

Volume Protection

- To avoid hearing loss, the maximum volume of this bone conduction headset is 85dB SPL in the Volume Protection Mode. The hearing level test method reference standard is ISO 8253-1:2010 (International Standard).
- Children under 13 are not recommended to use any electronic devices, including Aftershokz.
- Always turn the volume down to low level before placing the headphones on your (or your child's) head and Gradually turn up the volume to a comfortable level.
- Using headphones at high volume for a long time may cause hearing damage. To protect your hearing, please limit the use time at high volume.

How to Set Up Aeropex Play

1. Charge

Charge the headphones with the included magnetic charging cable. The LED indicator will turn from red to blue when charging is complete.

2. Pair

Start with your headphones powered off. Enter pairing mode by pressing and holding volume+ until Audrey says "pairing" and the LED indicator flashes red and blue.

3. Connect

Open your device's Bluetooth® menu and select "Aeropex Play by AfterShokz." Audrey says "connected" and the LED indicator will flash blue one time.

Let us take care of you! We've got your back against defects.
Register your Aeropex Play at
register.aftershokz.com

Multifunction Button (A)

Function	Action	Prompt / "Audrey Says™"
Play / pause music	Click once	One beep
Skip to next song	Double-click while music is playing	One beep
Back to previous song	Three-click while music is playing	One beep
Answer call	Click once	Two beeps
End call	Click once	One beep
Answer call waiting and hang up on current caller	Press and hold for 2 seconds	One beep
Reject a call	Press and hold for 2 seconds	Two beeps
Prompt device's voice assistant	Press and hold for 2 seconds	Device beep
Redial last number	Double-click (when idle)	"Redial last number"

Volume+ / Power Button (B); Volume- Button (C)

Function	Action	Prompt / "Audrey Says™"
Power on	Press and hold volume+ for 2 seconds	"Welcome to AfterShokz"
Power off	Press and hold volume+ for 3 seconds	"Power off"
Mute	Press and hold both buttons for 2 seconds while on a call	"Mute on" or "Mute off"
Power on /off volume limited	Press and hold both buttons for 3 seconds while music is playing	"volume limit enabled"/ "volume limit disabled"
Check battery status	Click the volume+ or volume- button while music is paused	"Battery high/Battery medium/ Battery low/Charge me"
Adjust volume	Click the volume+ or volume- button to adjust volume while music is playing	One beep

Specifications

Part number	AS800	**Frequency response**	20Hz~20kHz
Speaker type	Bone conduction transducer	**Sensitivity**	105 ± 3dB
Bluetooth® version	Bluetooth® v5.0	**Microphone**	-38dB ± 3dB
Wireless range	10 m	**Battery**	Li-Polymer battery
Compatible profiles	A2DP, AVRCP, HSP, HFP	**Weight**	25.2 g
Continuous play	Up to 8 hours	**Standby time**	Up to 10 days
Charge time	2 hours	**Warranty**	2 years
Frequency band	2402MHz~2480MHz	**Maximum RF output power**	4dBm
Charge voltage	5V±5%	**Water resistance**	IP67
Battery capacity	145 mAh		

LED Indicator

Solid red	Charging
Solid blue	Charging complete
Flashes red and blue	Pairing mode
Flashes blue	Incoming call
Flashes red every 2 minutes	Low battery

Multipoint Pairing

Multipoint pairing allows Aeropex Play to be connected to two devices at once, allowing users to seamlessly transition between the two.

1. Start with your headphones powered off.
2. Press and hold volume+ until Audrey says "pairing" and the LED indicator flashes red and blue.
3. Press and hold the multifunction button and volume+ button for 3 seconds. Audrey says "multipoint enabled."
4. Open your first device's Bluetooth® menu and select "Aeropex Play by AfterShokz." Audrey says "connected".
5. Turn your headphones off.
6. Re-enter pairing mode by pressing and holding volume+ until Audrey says "pairing" and the LED indicator flashes red and blue.
7. Open your second device's Bluetooth® menu and select "Aeropex Play by AfterShokz." Audrey says "connected."
8. Turn your headphones off.
9. Turn your headphones on. Your headphones are now connected to both devices.
10. To turn multipoint pairing off: Press and hold the multifunction button and volume- button for 3 seconds. Audrey says "multipoint disabled."

More information: bit.ly/ASMultipoint

Moisture Detected Alert

These headphones can detect liquid such as water, sweat, and rain. If the headphones are plugged into the charger while wet, the LED indicator will flash red and blue. The headphones will also vibrate and emit a beep. If this happens, remove the charging cable from the headphones, dry them completely and then proceed with charging.

How to Reset Your Headphones

1. Start with your headphones powered off.
2. Enter pairing mode by pressing and holding volume+ until Audrey says "pairing" and the LED indicator flashes red and blue.
3. Press and hold the multifunction button, volume+ button and volume- button (all three buttons) simultaneously for 3-5 seconds, until you hear two beeps or feel vibrations.
4. Turn your headphones off. Aeropex Play is now reset and can be re-paired to your device.

Optional Accessories

Earplugs (D)

Use with headphones in environments where it is safe to block out ambient noise, such as on a train or airplane.

1. Roll earplugs firmly between fingers and place in ears.
2. While music is playing to adjust EQ settings to reduce or enhance bass while wearing earplugs, press and hold volume+ and volume- buttons simultaneously.
3. Switch EQ to original setting when you take out the earplugs.

Manufacturer

AfterShokz LLC

6057 Corporate Dr., East Syracuse, NY 13057

한국어

음량 제한

- 장력 보호를 위해 이어폰의 최대 음량 제한모드에서 85dBSPL로 제한합니다. ISO 8253-1:2010(국제 표준)을 준수합니다.
- 13세 이하는 권장 기기 사용을 권하지 않습니다.
- 이어폰을 착용하기 전에(혹은 아이가 사용하기 전) 항상 음량을 낮게 설정하고 v 조금씩 적당한 음량으로 조절해 주세요.
- 높은 음량으로 장시간 사용 시 청력에 문제가 발생할 수 있으니 주의해 주세요.

Aeropex Play 세팅 방법

1. 충전

동봉되어진 마그네틱 자석 충전 단자로 충전해 주세요.충전이 완료되면 LED 표시가 빨간색에서 파란색으로 변경됩니다.

2. 블루투스 연결 (페어링)

제품이 꺼져있는 상태에서 파워버튼을 5초이상 누르고 있으면 페어링 모드로 들어갑니다. LED 불빛이 파란색과 빨간색이 번갈아 가며 깜박거리면 블루투스 연결을 시도하고 있다는 뜻입니다.

3.연결

디바이스의 블루투스 목록에서 'Aeropex Play by AfterShokz' 를 선택하면, "Connected"라는 음성 메세지가 나오면서 파란색 불빛이 한 번 깜빡거립니다.

www.aftershokz.kr 사이트에서 제품 시리얼을 등록하면 2년간 A/S를 보장 받으실 수 있습니다.

다기능 버튼 (A)

기능	작동 방법	Audrey Says
노래 재생/정지	한 번 누르세요	One beep
다음 곡 재생	노래를 듣는 중에 두 번 클릭하세요	One beep
이전 곡 재생	노래를 듣는 중에 세 번 클릭하세요	One beep
전화 응답	한 번 누르세요	Two beeps
전화 종료	한 번 누르세요	One beep
대기중인 수신자 응답 &전 통화 종료	2초 동안 누르고 기다리세요	One beep
수신 거부	2초 동안 누르고 기다리세요	Two beeps
음성 다이얼	2초 동안 누르고 기다리세요	Device beep
재 다이얼	두 번 누르세요	"리다이얼"

볼륨 업/파워 버튼 (B);볼륨 다운 버튼(C)

기능	작동 방법	Audrey Says
전원 작동	B 버튼을 2초 동안 누르고 기다리세요	"안녕하세요, 애프터샥입니다."
종료	B 버튼을 3초 동안 누르고 기다리세요	"전원을 종료합니다."
음소거	통화 중에 B, C 버튼을 동시에 2초 동안 누르세요	"음소거" / "음소거 끄기"
음량 제한	음악 재생 중 음량 +, 음량 – 버튼을 동시에 3초 동안 누르세요.	"음량 제한을 실행합니다" "음량 제한을 종료합니다"
배터리 상태 확인	노래 재생이 정지된 상태에서 B 혹은 C버튼을 클릭하세요	"배터리가 충분합니다, 배터리가 양호합니다, 배터리가 부족합니다, 충전해 주세요"
볼륨 조절	B혹은 C 버튼으로 조절하세요	One beep

특징

파트넘버	AS800	스피커 타입	골전도 트랜스듀서
통신 주파수	20Hz~20kHz	감도	105 ± 3dB
음량	-38dB ± 3dB	블루투스 버전	Bluetooth® v5.0
프로파일	A2DP, AVRCP, HSP, HFP	무선통신거리	10m
배터리	리튬 이온	연속 재생 시간	8시간
대기 시간	10일	충전 시간	2 시간
무게	25.2 g	보증기간	2년
충전 전압	5V±5%	생활방수	IP67
스피커 임피던스	8.5ohms±20%	배터리 용량	145 mAh
최대 무선주파수 출력			4dBm
블루투스 주파수 범위			2402MHz~2480MHz

멀티포인트 페어링

Aeropex Play를 2개의 기기와 동시에 연결해 둘 수 있습니다. 사용할 기기를 바꿀 때마다 페어링 시킬 필요 없이, 간단히 전환할 수 있습니다. 단, 페어링한 기기를 동시에 사용하는 것은 불가능합니다.

1. 우선 헤드폰을 전원이 꺼져있는 상태에서 시작하세요.
2. + 버튼을 LED가 파란색과 빨간색이 번갈아 가며 깜빡 거리며, "페어링" 이라는 소리가 날 때까지 눌러주세요
3. 다기능 버튼과 + 버튼을 "멀티포인트가 가능합니다" 라는 소리가 날 때까지 3초 이상 눌러주세요.
4. 첫 번째로 연결할 디바이스의 블루투스 목록에서 'Aeropex Play by AfterShokz' 를 선택하면 "연결되었습니다"라는 음성 메세지가 나옵니다.
5. 헤드폰을 꺼주세요
6. 다시 + 버튼을 "페어링"이라는 소리가 나며 파란색과 빨간색 불빛이 깜박일 때까지 눌러줍니다.
7. 두 번째로 연결할 디바이스의 블루투스 설정을 켜고, 연결 가능한 리스트에서 'Aeropex Play by AfterShokz' 를 선택하면 "연결되었습니다" 라는 음성 메세지가 나옵니다.
8. 헤드폰을 다시 꺼주세요.
9. 다시 헤드폰을 켜면 두 개의 디바이스에 모두 연결이 됩니다.
10. 멀티포인트 페어링을 해제하려면다기능 버튼과 – 버튼을 "멀티포인트가 불가능 합니다" 라는 소리가 날 때까지3초 이상 눌러주세요.

더 자세한 설명을 원하신다면 : *bit.ly/ASMultipoint*

LED 표시 불빛

빨간색	충전 중
파란색	충전 완료
빨간색 + 파란색 깜빡임	페어링 모드
파란색 깜빡임	전화 수신 중
2초 마다 빨간색 깜빡임	배터리 부족

재설정 하는 법

1. 헤드폰을 끈 상태에서 시작하세요.
2. + 버튼을 LED가 파란색과 빨간색이 번갈아 가며 깜빡 거리고, "페어링" 이라는 소리가 날 때까지 눌러주세요
3. 다기능 버튼과 볼륨 +, – 버튼을 신호음 혹은 진동이 느껴질 때까지 동시에 3~5초 동안 누르세요.
4. 다시 헤드폰을 끄세요. Aeropex Play가 리셋 되었습니다. 기기와 다시 페어링 할 수 있습니다.

충전 단자 경고

Aeropex Play는 액체 전여물을 감지할 수 있습니다. 충전부에 땀 또는 액체 전여물이 있는 경우 LED 표시가 빠르게 파란색 그리고 빨간색으로 점멸합니다. Aeropex Play가 진동하며 "Di-Di" 라는 소리가 들립니다. 충전부를 충분히 건조하게 한 후 정상적으로 충전할 수 있습니다.

액세서리

귀마개 (D)

비행기 혹은 기차와 같은 소음이 많은 환경에서 사용하세요.

1. 귀마개를 귀에 꽂으세요.
2. 귀마개를 하고 있는 동안에는 베이스를 줄이기 위해 EQ 세팅을 조절하세요.더욱 편안하게 음악을 들을 수 있습니다.

日本語

最大音量制限

- 難聴などの聴覚障害リスクを軽減するために、この骨伝導ヘッドホンは、音量制限モードで85dBSPLになっています。聴力レベル試験方法の参照規格は、ISO 8253-1:2010（国際規格）です。
- 13歳未満の子どもには、Aftershokzを含む電子機器の使用は推奨しません。
- 耳へのダメージを防ぐために、ヘッドホンを頭に装着する前に、必ず音量を最小に設定してから装着し、徐々に音量を適切なレベルにまで上げるようにしてください。
- ヘッドホンを大音量で長時間ご使用になられますと、聴力に悪影響を及ぼす可能性があります。聴力を保護するため、長時間・大音量でご継続的に使用することは避けてください。

Aeropex Play(エアロペクス・プレイ)の設定方法

1.充電

同梱の充電ケーブルを使用して充電してください。充電中はLEDが赤色に点灯し、充電が完了すると青色の点灯に切り替わります。

2. ペアリング

電源ボタンを5秒押すとペアリングモードに入り、赤色と青色のLEDが交互に点滅します。

3. 接続方法

端末のBluetooth設定から、Aeropex Play by AfterShokz を選択します。完了すると、オードリー が " 接続しました " と音声ガイダンスを行い、LEDが青く一度点灯します。

マルチボタン(A)

機能	操作方法	音声案内
音楽再生/一時停止	1回押し	ビープ音1回
次の曲にスキップ	音楽再生時に2回押し	ビープ音1回
前の曲にスキップ	音楽再生時に3回押し	ビープ音1回
電話に出る	1回押し	ビープ音2回
電話を切る	1回押し	ビープ音1回
音量制限機能を有効/解除	音楽の再生中に、両方のボタンを3秒間押し続けてください。	"音量制限を有効にしました。" "音量制限を解除しました。"
現在の通話を切って、二つ目の着信に出る	通話時に2秒間長押し	ビープ音1回
通話を拒否する	着信時に2秒間長押し	ビープ音2回
音声ダイヤル	2秒間長押し	ビープ音
最後に発信した番号をリダイヤルする	音楽停止時に2回押し	"リダイヤルします"

音量+ / 電源ボタン (B) :音量- (C)

機能	操作方法	音声案内
電源オン	音量＋ボタンを2秒間長押し	"アフターショックスへ、ようこそ"
電源オフ	電源ボタンを3秒間長押し	"終了します"
ミュート	通話時にBとCボタンを約2秒間長押し	"ミュートしました" "ミュートを解除しました"
バッテリ残量チェック	音楽静止時に音量ボタン(＋/－)のいずれかを1回押し	"充電されています" "およそ半分です" "残りわずかです" "充電してください" *
音量調整	音楽再生時に音量ボタン(＋/－)を 1回押し	ビープ音1回

イヤホン仕様

型番	AS800	スピーカー	Bone conductionスピーカー
周波数帯	20Hz~20kHz	感度	105 ± 3dB
マイク感度	-38dB ± 3dB	Bluetooth接続距離	約10m
バッテリー	リチウムバッテリー	連続再生時間	8 時間
待機時間	10日間	充電時間	2 時間
重量	25.2 g	保証時間	2 年
充電圧	5V±5%	防滴	IP67
最大高周波出力	4dBm	バッテリー容量	145 mAh
Bluetoothバージョン			Bluetooth® v5.0
対応プロファイル			A2DP, AVRCP,HSP, HFP
Bluetooth周波数帯			2402MHz~2480MHz

2台のデバイスを同時接続する方法

マルチポイント接続を利用することで、Aeropex Playを二つの端末にペアリング可能です。
これにより、二つの端末でもスムーズな切り替えが行えます。

1. ヘッドフォンをオフにします。
2. オードリー が " ペアリング " と音声ガイダンスを行い、LEDが青と赤に点滅するまで、ボリュームボタン(＋)を長押しして、ペアリングモードに移行します。
3. マルチファンクションボタンとボリュームボタン(＋)を3秒間長押しします。オードリー が " マルチポイント イネーブルド " と音声ガイダンスを行います。
4. 1台目の端末のBluetooth設定から、Aeropex Play by AfterShokz を選択しペアリングします。完了すると、オードリー が " コネクテッド " と音声ガイダンスを行います。
5. ヘッドホンをオフにします。
6. オードリー が " ペアリング " と音声ガイダンスを行い、LEDが青と赤に点滅するまで、ボリュームボタン(＋)を長押しして、ペアリングモードに移行します。
7. 2台目の端末のBluetooth設定から、Aeropex Play by AfterShokz を選択しペアリングします。完了すると、オードリー が " コネクテッド " と音声ガイダンスを行います。
8. ヘッドホンをオフにします。
9. ヘッドホンをオンにすると、どちらの端末にも接続した状態となります。
10. マルチポイント接続をオフにするには、マルチファンクションボタンと音量－ボタンを3秒間長押しします。オードリー が " マルチポイント接続を終了します " と音声ガイダンスを行います。

詳しい情報は、bit.ly/ASMultipointをご覧ください。

LED表示

赤色（常時点灯）	充電中
青色（常時点灯）	充電完了
赤色と青色で交互に点滅	ペアリングモード
青色（点滅）	着信
赤色（点滅）	バッテリー残量低下

出荷時の設定に戻す(初期化)

1. ヘッドホンをオフにします。
2. オードリー が " ペアリング " と音声ガイダンスを行い、LEDが青と赤に点滅するまで、ボリュームボタン(＋)を長押しして、ペアリングモードに移行します。
3. マルチファンクションボタン、ボリュームボタン(＋)、ボリュームボタン(－)の3つのすべてのボタンを、ヘッドホンから2回のビープ音が鳴こえるか、振動を感じるまで、3～5秒間長押しします。
4. ヘッドホンをオフにします。Aeropex Playのリセットが完了したので、ペアリングを再度行います。

漏電防止アラート

本製品は、マグネット充電端子に付着した汗やその他の液体などを検出する「漏電防止アラート」を搭載しています。アラート発動時にはLEDが青と赤に点滅し、本体が振動するとともにビープ音でお知らせします。マグネット充電端子に付着した液体を十分に乾かしてから、再度充電を行ってください。

オプション品

耳栓（D）

耳栓と「Aeropex Play」を一緒に使用することで、周りの騒音を拾わずに快適な環境で音楽を聴くことができます。

1. 耳栓を小さく潰して、耳に入れてください。
2. 音楽再生時、イコライザーを調整することで快適なオーディオビジュアルを体験することができます。