COLOR-CHANGE

• Cold water color change will start at approximately 59ºF (15ºC), but best results occur if the ice water is chilled to approximately 32ºF (0ºC) or colder.
• Only the wigs on certain Tiny Toys will color change in cold water or in the sunlight.
• A UV light will work as well on Tiny Toys that change color in the sunlight.
• For UV color change, remove from sunlight to return it to its original color.
• If color change does not work properly or quickly, the temperature of the Tiny Toy's body may be too close to the temperature of the water.
• Color change temperatures may vary according to weather conditions.
• The color-change effect has a lengthy, but limited lifespan.

IMPORTANT INFORMATION

• Before beginning, cover the play area to protect from possible water damage.
• An adult must be present when children are playing with water.
• Do not bend or twist your Tiny Toy's head or body.
• When removing the wig, hold it from the bottom of its head and body. Then, carefully remove the wig.
• Wigs are interchangeable between Tiny Toys with the same head bun or buns.
• **Only one Tiny Toy is included. Multiple characters shown for demonstration only.**
• **Only the wigs on the characters shown in this manual will have a special feature.**
• For Tiny Toys that glow in the dark, hold it in the light for a few minutes and then place it in a dark room.
• Do not place the Tiny Toy in extremely hot water.
• Do not store the Tiny Toy in direct sunlight for extended periods of time.
• Air dry only. Do not place in the dryer or subject to excessive heat.
• Exposure to sunlight may deactivate color change feature.
• Insert the backdrop in the display case. Backdrop can also be removed.
• Only one display case is included. Multiple display cases are shown for demonstration only.
• After attaching multiple display cases. Replace the lid to lock in place.
• Do not play with assembled Glamper in the street, where there is vehicular traffic or in heavily traveled areas with pedestrians.
• Do not run or throw the assembled Glamper into furniture, walls, pets, people, etc., as doing so may cause injury to the person and irreparable damage to the unit.
• Do not drive assembled Glamper through water, mud, etc.

Please keep this manual as it contains important information.

L.O.L. SURPRISE! TINY TOYS

SKUs: 565802 / 565802x1

AGES 3+

ADULT SUPERVISION REQUIRED

CONTENTS

A. 1 Tiny Toy

B. 1 Interchangeable Wig (Ultra-rare will come with 2 wigs)

C. 1 **Part** of the Glamper (Ultra-rare will come with 4 parts)

D. 1 Display Case

E. 1 Backdrop

Illustrations are for reference only. Styles may vary from actual contents.

TINY TOY

DISPLAY CASE

GLAMPER ASSEMBLY

BEFORE STARTING

• Make sure you have collected each part. Some assembly is one-time snap. Once wheels have been snapped in place, they can't be removed.
• Follow the below steps in order when assembling the Glamper.

①	②	③	④	⑤	⑥	⑦	⑧	⑨
⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱ x4

TIP: Part number is located under each piece.

1 ⑯ ⑰

2 ⑭ ⑮

3 ⑫ ⑬ ⑪

4 ⑭ + ⑮ ⑯ + ⑰ ⑧ ⑨

5 ⑫ + ⑬ ⑧ + ⑭ + ⑮

6 ⑱ ⑱ ⑱ ⑱

7 ④ ② ③ ⑦

8 ② ③ ④ ⑦

9 ⑤ ⑥

10 ① ⑤ + ⑥

TIPS: · Some force is needed to snap the wheels in.
· Once the wheels have been snapped in, they can't be removed.