
for backlight only on at night:
tap into an existing
dash illumination
wire nearby in the
dash button cluster
12v
for backlight on whenever
truck is on:
same 12v source
as amber lights
in-line
5A fuse
TRD
LIGHT BAR
-
+
car battery
or aux fuse box