CRONUS ZEN

QUICK START GUIDE

VIEW FULL MANUAL AT
ZEN.CRONUSMAX.COM/MANUAL

 @CMGamingCo   @CMGamingCo   @CMGamingCo

WHAT'S IN THE BOX

1 (1) CRONUS ZEN

Bluetooth Pair Button
Zen Message Center
Memory Slot Button
RGB LEDs
Micro USB (back of the device)

P2
SCREEN
P1
EYES
CONSOLE

A1 **A3** **A2**
LEDs Status
PROG Mini USB

Pass-thru Console Controller Wired or USB Cable
Crossover Controller Ports Including Mouse & Keyboard

2 (1) MICRO USB CABLE SHORT

3 (1) MICRO USB CABLE LONG

4 (1) MINI USB CABLE LONG

GETTING STARTED

1 Download & Install Zen Studio Software

visit **zen.cronusmax.com/download**

2 Connect the Cronus Zen to your computer using the PROG USB port and the mini USB cable provided

3 Once connected the Zen Studio software will recognize your Cronus Zen

Requirements

- Microsoft Windows 10 is recommended for Zen Studio.

- A wired, licensed controller that matches the console. Wireless controllers can be used with a full data USB cable.

- Note: XBOX 360 console support requires a fully wired X360 controller. The 'Play and Charge Kit' for wireless X360 controllers will not work.

WIRED CONTROLLER SETUP

CONNECT YOUR CONSOLE
Connect the Cronus Zen to your console using the micro USB cable provided

1

XBOX ONE, PS4, XBOX 360, PS3 & NINTENDO SWITCH SUPPORTED

2 **PASS-THRU CONTROLLER**
Connect a wired controller that matches your current console

CONNECT CROSSOVER CONTROLLER
Connect your desired crossover controller to port A2 or A3

3

All connected status LEDs should be green and the current console displayed on the Zen Message Screen

ENABLE WIRED COMMUNICATION
Nintendo Switch
System Settings > Controllers & Sensors > Select: Pro Controller Wired Com

WIRELESS CONTROLLER SETUP

XBOX ONE BLUETOOTH

1 Turn on your controller

2 Press the Sync button on the controller

3 Press the Bluetooth pairing button on the Cronus Zen The Zen RGB LED will flash blue, showing Bluetooth pairing has begun.

4 Within 30 seconds the Zen RGB LED will change to white and the controller will vibrate when pairing is complete.

5 You are now connected!

DUALSHOCK 4

1 Turn off your controller

2 Hold Share + Home until the light bar flashes white

Note: Only DUALSHOCK 4 model CUHZCT2 supports headsets and the built in speaker.

OTHER SUPPORTED CONTROLLERS				
	DUALSHOCK 3	SWITCH PRO	JOY CON	Wii U PRO

Connection instructions for these controllers available at **zen.cronusmax.com/manual**

WIRELESS ADAPTER USAGE

1 Plug the controller into **USB port A2** of the Cronus Zen using the Micro USB cable. It will vibrate to indicate it's connected.

2 Insert the XBOX ONE wireless adapter into **USB port A3** of the Cronus Zen.

3 Unplug the controller from **USB port A2**. The XBOX button will begin to flash.

4 Within a few seconds the wireless adapter's **LED will change to white** and your controllers XBOX button will stay solid, indicating paring is complete.

5 You are now connected to the Cronus Zen and the controller is ready to use. If the controller is not connected, remove the batteries and repeat the steps above.

XBOX 360 WIRELESS

1 Plug the XBOX 360 Wireless Gaming Receiver into **USB port A2** of the Cronus Zen.

2 **Turn on** the XBOX 360 Wireless Controller.

3 Press the **SYNC button** on your controller until the Guide button flashes.

4 Press the **SYNC button** on the XBOX 360 Wireless Gaming Receiver.

5 Within a few seconds the lights on the guide button will stay solid, indicating pairing is complete and your controller is ready to use.

WIRELESS ADAPTER SETUP

MOUSE & KEYBOARD SETUP

1 Connect your console pass-thru controller to **USB Port A1** of the Cronus Zen.

2 Connect the mouse and keyboard to **USB Ports A2** and **A3** of the Cronus Zen.

3 Connect the Cronus Zen to your computer using the Mini USB Cable.

4 Open up the Zen Studio Software on your computer & load the **M&K Settings Plugin**.

5 Configure your **game profile in M&K Settings** and finalize the layout.

6 Unplug from your PC and connect the Cronus Zen to your console using the Micro USB cable.

SCRIPTS: Thousands of scripts are available in the GPC Script Library or you can write your own and share with the Cronus Community.

GO TO ZEN STUDIO › LIBRARY

GAMEPACKS: are created by expert gamers who spend hours playing the most recent titles, unlocking MODS and exploits engineered specifically for each game.

GO TO ZEN STUDIO › PROGRAMMER

Zen Studio Software

GAMEPACKS & SCRIPTS

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, theuser is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction